Windows

Panasonic

Network Operation Manual

(Wireless Manager mobile edition 5.5)



※ The projectors illustrated as examples are PT-FW300NTE.

ENGLISH

TQBH0205-4 (E/U/EA)

Contents

Software Licensing Agreement 3
Notes on Using Wireless Connection 4
Request Regarding Security 6

What you can do with Wireless Manager mobile edition 5.5 ... 7
Check your computer 10
Necessary environment for computers to be connected 10

Software requirements 12
System requirements 12

Installing and using software 13
[1. Wireless Manager ME 5.5] 13

Installation free set up 14

[Installation free set up] 14

Connecting with wireless LAN 15
Preparations 15
Easy Wireless Set Up 15
Parts name in search screen 15
"S-MAP" Connection 18
"1-4/U" Connection 19

"PC Search" Connection 20
Connection error messages 22
Connecting through the access point 24
When logging on without administrator authority 25

Connecting with Wired LAN 28

Other operations for connection 29
Operations when password entry is required for connection 29

Other search 29
Automatic connection by "One-click connection" 30
Exit Wireless Manager 31

Various projection methods 32
Description of the launcher 32
Live Mode 34
Multi Live Mode 35
Switching from one style to another 35

4-screen multi style 36
4-screen index style 37
16-screen index style 39
Multiple Source Live Mode 40
Multiple Source Multi Live Mode 42

Useful Functions 44
Selective Area Transmission 44
Secondary display transmission 45
Secondary Viewer 45

AV Mute function 46
Pointer function 46
List of connectable projectors/available functions in each projection method 47

Setting options 48
Setting options 48
Transmission 48

Key setting 49
Other1 49
Other2 50
Version information 50

Network/Security setting of the projector 51
Displaying the Network Menu 51
Wired LAN settings 52
Default wired LAN settings 52
Setting network number (for wireless LAN) 53
[USER] settings 53
Setting IP 53
Wireless settings 54
Default settings of [USER1] - [USER3] 55

Changing the projector name 56
Password setting 56
Network standby 57
Network control 57
Live mode cut-in 58
Computer search 58
Multi-live 58
Verifying settings 59
Returning to the initial settings 59

Using WebBrowser 60
Before using the WebBrowser control 60
Accessing from the WebBrowser 61
Monitor information window 62

Projector control window 63
Detailed settings window 64
Switching Languages 67

Using PJLink™ protocol 68

Applicable commands 68

Software Uninstall 69

Wireless Manager ME 5.5 69

Glossary 70

Frequently Asked Questions 72

Software Licensing Agreement

Use of this Software is governed by the terms defined in this Software Licensing Agreement.

● Article 1 License

The users obtain the license of the software (i.e. the information recorded or contained in CD-ROM, operation manual or others), but the copyright or intellectual property right of the software does not transfer to the users.

● Article 2 Use by a Third Party

Licensee may not transfer or allow any third party, to use or copy the Software, whether free of charge or not.

● Article 3 Restrictions on Copying the Software

Licensee may make a single copy of the Software in whole or in part solely for backup purposes.

● Article 4 Computer

Licensee may install and use the Software on more than one computer owned or managed by Licensee.

● Article 5 Reverse Engineering, Decompiling or Disassembly

Licensee may not reverse engineer, decompile or disassemble the Software. Panasonic shall not be bound by warranty for any defects in the Software caused by Licensee's reverse engineering, decompiling or disassembly of the Software. Furthermore, Panasonic or its distributors or dealers will not be responsible for any damage to the Licensee caused by Licensee's reverse engineering, decompiling or disassembly of the Software.

● Article 6 After-sales Service

If you have a problem with the software, please contact the customer support center by telephone. Panasonic shall undertake to notify Licensee of whether the problem is a known error in the program ("bug"), or whether the way in which the Software is to be used should be modified.
Furthermore, the Software is subject to revision without prior notice.

● Article 7 Indemnification

Panasonic's liability with respect to this Software is limited to the conditions defined in Article 6 herein.
Panasonic or any of its distributors or dealers shall not be liable for any damage suffered by Licensee, either directly or through claims from a third party, arising from or in connection with Licensee's use of the Software.
Furthermore, Panasonic Corporation does not guarantee the successful operation of the software unless it is used with any of Panasonic projectors.

● Article 8 Export Control

Licensee agrees not to export or re-export the Software to any county other than the country of purchase of the projector in any form without the appropriate export licenses under the regulations of the country where Licensee resides or of any other country as may be required by such export or re-export.

Wireless Manager mobile edition 5.5 (hereinafter called "Wireless Manager ME 5.5") uses the following software programs:
Portion of this software are based in part on the work of the Independent JPEG Group

Please note the following.

- Panasonic cannot be held liable for any direct or indirect damages resulting from the use or malfunction of this projector.
- Panasonic cannot be held liable for damages arising from data corruption or loss as a result of using this projector.

Notes on Using Wireless Connection

Wireless connection function of the projector uses radio waves in the 2.4 GHz band.
A radio station license is not required, but be sure to read and fully understand the following items before use.

■Do not use near other wireless equipment.

The following equipment may use radio waves in the same band as the projector.
When the projector is used near these devices, radio wave interference may make communication impossible, or the communication speed may become slower.

- Microwave ovens, etc.
- Industrial, chemical and medical equipment, etc.
- In-plant radio stations for identifying moving objects such as those used in factory manufacturing lines, etc.
- Designated low-power radio stations

■If at all possible, avoid the use of cellular phones, TV sets or radios near the projector.

Cellular phones, TV sets, radios and similar devices use different radio bands from the projector, so there is no effect on wireless communication or the transmission and reception of these devices. However, radio waves from the projector may produce audio or video noise.

■Wireless communication radio waves cannot penetrate steel reinforcements, metal, concrete, etc.

Communication is possible through walls and floors made from materials such as wood and glass (except glass containing wire mesh), but not through walls and floors made from steel reinforcements, metal, concrete, etc.

■Avoid using the projector in locations prone to static electricity.

If the projector is used in a location prone to static electricity, such as on a carpet, the wireless LAN or wired LAN connection may be lost.
If this happens, eliminate the source of static electricity or electromagnetic noise and reconnect to the wireless LAN or wired LAN.
In rare cases static electricity or electromagnetic noise may make it impossible to establish a connection to the LAN.
If this happens, press the power button on the remote control or on the projector to power off the projector temporarily.
After the cooling fan stops operating (after the power monitor on the projector changes from orange to red), power on the projector and reconnect to the LAN.

■Using the projector outside the country

It is forbidden to take the projector outside the country or region where you purchased it, so use it only in the said country or region. Also, note that depending on countries or regions there are restrictions on the channels and frequencies at which you can use the wireless LAN.

Notes on Using Wireless Connection (cont.)

■Channels that can be used

The channels (frequency range) that can be used differ according to the country or region. Refer to the table below.

Country or region	Standard	Channels used	Frequency band (Center frequency)
Japan	ARIB STD-T66	1 - 13	2,412 MHz - 2,472 MHz
China	SRRC		
England, Germany, France, Spain, Italy, Belgium, Austria, Sweden, Norway, Denmark, Switzerland, Holland, Finland, Portugal, Greece, Thailand, South Korea	ETSI 300.328		
Singapore	IDA		
Australia, New Zealand	C-Tick		
Malaysia	SIRIM		
United States	FCC part 15	1 - 11	2,412 MHz - 2,462 MHz
Taiwan	DGT		

■Wired LAN

Use straight or crossover LAN cable that is compatible with category 5 or above.

※1: Use category 5e or above when using 1000BASE-T.

※2: Whether straight cable, crossover cable or both can be used varies depending on the system configuration. For details, consult your system administrator.

Request Regarding Security

When using this product, security breaches of the type described below are conceivable.
- Leakage of your private information via this product
- Illegal operation of this product by a malicious third-party
- Harm to or cessation of operation of this product by a malicious third-party

Be sure to implement sufficient security measures.
- Set passwords, and limit the users that are permitted login access.
- Make sure the password is as hard to guess as possible.
- Change the password periodically.
- Panasonic Corporation and its affiliated companies never directly ask customers for their password.
  Do not give out your password even if directly asked by a third-party representing themselves as Panasonic Corporation.
- Always use on a network that has safety protection such as a firewall implemented.

About Wireless LANs

The advantage of a wireless LAN is that information can be exchanged between a PC or other such equipment and an access point using radio waves as long as you are within range for radio transmissions.
On the other hand, because the radio waves can travel through obstacles (such as walls) and are available everywhere within a given range, problems of the type listed below may occur if security-related settings are not made.

- A malicious third-part may intentionally intercept and monitor transmitted data including the content of e-mail and personal information such as your ID, password, and/or credit card numbers.

- A malicious third-party may access your personal or corporate network without authorization and engage in the following types of behavior.
  Retrieve personal and/or secret information (information leak)
  Spread false information by impersonating a particular person (spoofing)
  Overwrite intercepted communications and issue false data (tampering)
  Spread harmful software such as a computer virus and crash your data and/or system (system crash)

Since most wireless LAN adapters or access points are equipped with security features to take care of these problems, you can reduce the possibility of these problems occurring when using this product by making the appropriate security settings for the wireless LAN device.

Some wireless LAN devices may not be set for security immediately after purchase. To decrease the possibility of occurrence of security problems, before using any wireless LAN devices, be absolutely sure to make all security-related settings according to the instructions given in the operation manuals supplied with them.
Depending on the specifications of the wireless LAN, a malicious third-party may be able to break security settings by special means.
Please contact Panasonic if you need help taking care of security settings or other such.
If you cannot perform security settings for your wireless LAN by yourself, please contact the Panasonic Support Center.

Panasonic asks customers to thoroughly understand the risk of using this product without making security settings, and recommends that the customer make security settings at their own discretion and responsibility.

What you can do with Wireless Manager mobile edition 5.5

● Network Transmission

You can connect the projector to a computer via the wireless LAN or the wired LAN, and send moving and still images.
For information on the connection, refer to the description on page 15 for wireless LAN, and page 28 for wired LAN.

● Project with various methods

<Live mode> (See page 34)



Used for normal presentations.

<Multi live mode> (See page 35)

- 4-screen multi style (See page 36)



Used for presentations involving multiple computers.

- 4-screen index style (See page 37)



This style is convenient in cases where you wish to focus attention on one of four presentations displayed simultaneously.

- 16-screen index style (See page 39)



This style is convenient in cases where you wish to display a large number of presentations as a list.

What you can do with Wireless Manager mobile edition 5.5 (cont.)

● Project with multiple projectors

<Multiple source live mode> (See page 40)



This arrangement can be used when a number of projectors are installed in a large conference room, or when holding simultaneous presentations in several conference rooms, for example.

<Multiple source multi live mode> (See page 42)



This arrangement can be used when you wish to simultaneously display multiple presentations using multiple projectors.

● Useful functions

<Selective area transmission> (See page 44)



By using the selective area window, you can specify the necessary information alone from the computer screen, and display it on the projection screen.

<Secondary display transmission> (See page 45)



You can set the computer screen and the projector screen to the multi-monitor mode, and use the computer screen as the primary monitor and the projector screen as the secondary monitor. This is convenient for when holding a presentation using the projector screen while displaying reference material on the computer screen.

Note

For details on the secondary display transmission function, see the application section for the secondary display transmission function in the instruction manual.

Note

For connectable projectors and functions available for Wireless Manager ME 5.5, see “List of connectable projectors/available functions in each projection method” on page 47.

What you can do with Wireless Manager mobile edition 5.5 (cont.)

<WebBrowser control> (See page 60)
The following operations are possible when using WebBrowser.
• Setting and adjusting the projector
• Displaying the projector status
• Setting for message transmission

<PJLink™> (See page 68)
Compatible with PJLink™ Class 1. The following operations can be performed from a computer when PJLink™ protocol is used.
• Setting the projector
• Querying the projector status

<Command control> (Refer to "Serial terminals" in the operation manual for the projector.)
You can control the projector from a PC, using the control commands of the serial terminals.

<Virtual remote control function> (See page 33)
You can perform the following operation from a PC, using the virtual remote control in stead of the remote control.
• Changing the channels
• Turning the power on and off

<One-click Connection> (See page 30)
You can connect to the projector by double-clicking or using drag-and-drop.

<Live mode cut-in function> (See page 58)
During live mode or multi live mode, a different computer can interrupt and project images in live mode.

Note
If you use "Web control," "PJLink™" or "Command control," turn on [NETWORK CONTROL] in the network menu for the projector. (See page 57)

Check your computer

Necessary environment for computers to be connected

• First, check your computer to see whether or not it has a wired LAN※ or a built-in wireless LAN function.
※LAN : “Glossary” (See page 70)
• Before connecting the projector to the computer, be sure to check the following settings.
• Operation is not guaranteed for all wireless LAN adapters and built-in wireless LAN adapters.

■Wireless LAN

Check 1 **Wireless LAN settings**

<Computer with a built-in wireless LAN function>
• Is your wireless LAN switched on?
<Computer without a built-in wireless LAN function>
• Is your wireless LAN adapter properly recognized?
• Is the wireless LAN adapter switched on?
• Install the wireless LAN adapter driver beforehand.
For details on how to install the driver, refer to the instructions accompanying the wireless card.

Check 2 **Logon user’s settings**

• Have you logged in as the Administrator?

Check 3 **Computer’s settings**

• When security (firewall) software and utilities for network cards are installed, these may prevent connection of the projector.
<Windows XP/Windows Vista/Windows 7>
• Is Network Bridge enabled? (See page 73)
• Has your firewall been disabled? (See page 74)

Check your computer (cont.)

■Wired LAN

Check 1

<For wired LAN>

- Is the cable properly connected?
- The specifications for cables vary depending on the system configurations. Confirm the projector settings and the cable specification.

Check 2 **Wired LAN settings**

<Computer with a built-in wired LAN function>

- Is your wired LAN switched on?

<Computer without a built-in wired LAN function>

- Is your wired LAN adapter properly recognized?
- Is your wired LAN adapter switched on?
- Install the wired LAN adapter driver beforehand.
  For details on how to install the driver, refer to the instructions accompanying the wired LAN adapter.

Software requirements

System requirements

The computer must meet the following requirements in order to use the supplied software.

OS: Microsoft Windows® 7 Ultimate 32bit/Windows® 7 Home Premium 32bit/Windows® 7 Professional 32bit/ Microsoft Windows® 2000 Professional SP4/Microsoft Windows® XP Home Edition/Windows® XP Professional/ Windows® XP Tablet PC Edition 2005/Microsoft Windows® Vista® Ultimate 32 bit/Windows® Vista® Business 32 bit/ Windows® Vista® Home Premium 32 bit/Windows® Vista® Home Basic 32 bit

CPU: Intel® Pentium® III 800 MHz or faster, or compatible processor (1 GHz or faster is recommended when using live mode)

RAM: 256 MB or more

Empty hard disk capacity: 60 MB or more

Hardware conditions: CD or DVD drive (for installing software and viewing the operation manual)
LAN terminal (10BASE-T/100BASE-TX)
An IEEE802.11 b/g built-in wireless LAN system or an IEEE802.11 b/g wireless LAN adapter must be installed and running properly.
However, some IEEE802.11 b/g wireless LAN may not allow connection to IEEE802.11 g projectors.

WebBrowser: Internet Explorer® 6.0 or newer
Netscape Communicator 7.0 or newer

Notes

- Note that operation is not guaranteed when used with system environments other than the above or on homemade computers.
- Compatibility of Microsoft Windows® XP and Vista®
  Microsoft Windows® XP: SP3 or before
  Microsoft Windows® Vista®: SP2 or before

■Precautions when using Windows Vista/Windows 7

- The following limitation is applied to the projection of Launcher to the projector screen:
  – Software installed: Launcher is displayed.
  – Software not installed: When Windows Aero is engaged, the launcher is projected.
  When Windows Aero is disengaged, the launcher is not projected.
- When using a Windows® Vista® computer, you must be logged in to an administrator account in order to use the secondary display transmission function.
  Note that this function cannot be used in some operating environments.

Operation is not guaranteed for all computers that meet the above conditions.

Note

The illustrations and screenshots in this manual may be different from those on your computer.

Installing and using software

Notes

- Exit all the application software programs that are running on Windows. Otherwise, installation may not be possible.
- Administrator authority is required for installation.
- If the installer does not start up automatically, double-click [EasyInstall] → [Easy_Inst.exe] in the CD-ROM.
- If Wireless Manager ME 1.0, 2.0, 3.0, 4.0, 4.5 or 5.0 has been installed, uninstall it by following the method below.
  From the desktop, select [Start] → [All Programs] → [Panasonic Wireless Display] → [Uninstall Wireless Manager mobile edition *.*]. (*.* in the menu is 1.0, 2.0, 3.0, 4.0, 4.5 or 5.0)
  Follow the instructions appearing on the screen and uninstall the software.
- If Wireless Manager is used immediately after installation, some functions (secondary display transmission, etc.) may not work. In such a case, restart the computer once and then use Wireless Manager.

[1. Wireless Manager ME 5.5]

Wireless Manager ME 5.5 is used to send a screen from a PC to the projector via wireless or wired LAN.

1 Click [1. Wireless Manager ME 5.5].

Follow the instructions on the screen and install the software.

Installation free set up

[Installation free set up]

You can use Wireless Manager ME 5.5 without installing it in the computer.
If your PC can access the removable media such as SD card on which Wireless Manager ME 5.5 is copied, you can use without installing it.

Note

When copying Wireless Manager ME 5.5 to a removable medium, empty capacity of at least 32 MB is required.

1 Insert provided CD-ROM into the CD-ROM drive.

The install program starts.

2 Click [Installation Free Set Up].

[Direct CD-ROM Startup] and [Other Media Source Startup, Make Copy Here] appear on the window.

3 Ⓐ When using without copying the program: Click [Direct CD-ROM Startup].

Wireless Manager ME 5.5 starts.
Operation is the same as when operating after installing CD-ROM.

Ⓑ When using after copying the program: Click [Other Media Source Startup, Make Copy Here].

A window opens to select the destination to save.

<If you chose Ⓑ in step 3, follow steps 4 - 5.>

4 Select the destination to save, and click [OK].

CD-ROM data is copied to the destination.
Once Wireless Manager ME 5.5 has been copied, click [Close] in Easy Install dialog box.

5 Double-click the Wireless Manager ME 5.5 icon (WMStart.exe) for the destination folder “WMme5.5” you selected in step 4.

Wireless Manager ME 5.5 starts up.
Operation is the same as when operating after installing CD-ROM.
If selecting removable medium as the destination to save, ensure that the removable medium is recognized by the computer to which you wish to connect the projector.

Notes

- When using without installing, following functions are not available.
  - Secondary display transmission (See page 45)
  - Producing audio along with video at live mode (See page 48)
  - Automatic connection by double-clicking (See page 49)
  - Operation is slower compared to when the computer is used with Wireless Manager ME 5.5 installed.
- If you have logged in as a [GUEST] or other user that has no [Administrator] authority, use [U (user)] for the network number.

Connecting with wireless LAN

Preparations

Make sure or prepare for the following items:

① The wireless LAN adapter is recognized. (See page 72)
- The wireless LAN adapter you want to use is enabled. (Otherwise, enable it.)
- Make sure the power supply for the wireless LAN adapter is turned on; the hardware switch or the software setting might have turned it off.

② When using it via the infrastructure connection: Make sure the network setting for the projector has been done by the administrator. (For detailed information, refer to [USER] setting on page 53.)

③ If you log in with [User authority], select a projector network number from [USER1] to [USER3]. (For detailed information, refer to [USER] setting on page 53.)

Easy Wireless Set Up

There are 3 different connection methods, “S-MAP” (Projector Signal Map) Connection, “1-4/U” Connection, and “PC Search” Connection.
These connections enable easy search and connection to the projector.
(Refer to “1-4/U” connection on page 19 to establish an easy wireless connection with projectors that have no S-MAP function.)

- [S-MAP] Connection: Search and connect to the projectors set up using [Network Number] [S-MAP] (See page 53). Connectable projectors are displayed in order of wireless reception strength. (See page 18). Operation is performed in [S-MAP] or [S-MAP] (list display) view on the <Projector Search> window.
- [1-4/U] Connection: Search and connect to the projectors set up using [Network Number] [1]-[4] or [USER1]-[USER3]. Projectors that can be connected to are displayed in a list (See page 19). Operation is performed in [1-4/U] view on the <Projector Search> window.
- [PC Search] Connection: Use the [Computer search] function on the projector to search and connect (See page 20).

Parts name in search screen

■ <Projector Search> window – [S-MAP] (See page 18)



① **Setting menu display**
Choose to display or hide the ② to ⑥ buttons

② **Access Devices** (See pages 34, 40, 42)
When only one projector is connected, select [ ]. When multiple projectors are connected, select [ ].
※ Multiple projectors [(Multiple projectors icon)] are available when “1-4/U” is selected.

③ **S-MAP** (See page 18)
Display <Projector Search> window – [S-MAP].

④ **1-4/U** (See page 19)
Display <Projector Search> window – [1-4/U].

⑤ **PC Search** (See page 20)
Display <PC Search> window.

⑥ **Other search** (See page 29)
From the projectors that are currently switched on, search for the projector of specified IP address, domain name, and ID.

⑦ **Updates the list of found projectors.**

⑧ **Switching Display Window**
: <Projector Search> window – [S-MAP] is displayed. (Upper figure)
: <Projector Search> window – [S-MAP] (list display) is displayed. (See page 16)

⑨ **Found projectors**
- Projector found on a wired LAN
- Projector found using [U (user)]
- Projectors searched by a network number of 1 to 4.

⑩ **Projectors searched and found by S-MAP.**
The name and ID of projectors are displayed.
represents the projectors that were searched and found through wired LAN.
represents the projectors that were searched and found through wireless LAN.

Connecting with wireless LAN (cont.)

■ <Projector Search> Window – [S-MAP] (List display) (See page 18)



① **Setting menu display**
Choose to display or hide the ② to ⑥ buttons

② **Access Devices** (See pages 34, 40, 42)
When only one projector is connected, select [ ]. When multiple projectors are connected, select [ ].
※ Multiple projectors [(Multiple projectors icon)] are available when “1-4/U” is selected.

③ **S-MAP** (See page 18)
Display <Projector Search> window – [S-MAP].

④ **1-4/U** (See page 19)
Display <Projector Search> window – [1-4/U].

⑤ **PC Search** (See page 20)
Display <PC Search> window.

⑥ **Other search** (See page 29)
From the projectors that are currently switched on, search for the projector of specified IP address, domain name, and ID. (From all network numbers except for [U (user)])

⑦ **Updates the list of found projectors.**

⑧ **Switching Display Window**
: <Projector Search> window – [S-MAP] is displayed. (See page 15)
: <Projector Search> window – [S-MAP] (list display) is displayed. (Upper figure)

⑨ **This mark appears for the projectors that have been searched and found through wired LAN.**

⑩ **ID** (See page 29)
Display projector’s ID.

⑪ **Mode** (See page 34)
Display projector’s mode or style.

⑫ **Available modes and functions**
Unavailable modes/functions among [Live mode] and [Multi live mode] are displayed with [ ] overlaid on them.

⑬ **The number of people connected to this projector**
Display the number of people that are connected to this projector.

⑭ **The status of this projector**
Display the projector’s connection status.

⑮ **[ ] will be displayed when password is required for the connection.** (See page 29)

⑯ **Connection message**
Blinks when connection is not possible. Click to display information on resolving the issue. (See page 22)

⑰ **The [Projector Name] of the selected projector and the name given in the favorites are displayed (See page 49).**
Guides for the operating status and connection method etc are also displayed.

⑱ **Connectability**
The name and ID of projectors are displayed on the upper left of the selected projector’s projection screen.
Once it is confirmed as connectable, the message “Projector is available.” will appear on the PC screen.

⑲ **Connection**
Connect to the selected projector.

Connecting with wireless LAN (cont.)

■ <Projector Search> Window – [1-4/U] (See page 19)



① **Setting menu display**
Choose to display or hide the ② to ⑥ buttons

② **Access Devices** (See pages 34, 40, 42)
When only one projector is connected, select [ ]. When multiple projectors are connected, select [ ].
※ Multiple projectors [(Multiple projectors icon)] are available when "1-4/U" is selected.

③ **S-MAP** (See page 18)
Display <Projector Search> window – [S-MAP].

④ **1-4/U** (See page 19)
Display <Projector Search> window – [1-4/U].

⑤ **PC Search** (See page 20)
Display <PC Search> window.

⑥ **Other search** (See page 29)
From the projectors that are currently switched on, search for the projector of specified IP address, domain name, and ID. (From all network numbers except for [U (user)])

⑦ **Update the connection status display**

⑧ **"Network" number**
If you specify [1], [2], [3], [4], [U (user)]※1 or [Display all], the projector(s) assigned with the corresponding network number(s) will be displayed in [Projector name] field (See page 53). The default value is [S-MAP]※2 for both PC and projector.

⑨ **This mark appears for the projectors that have been searched and found through wired LAN.**

⑩ **ID** (See page 29)
Display projector's ID.

⑪ **Mode** (See page 34)
Display projector's mode or style.

⑫ **Available modes and functions**
Unavailable modes/functions among [Live mode] and [Multi live mode] are displayed with [ ] overlaid on them.

⑬ **The number of people connected to this projector**
Display the number of people that are connected to this projector.

⑭ **The status of this projector**
Display the projector's connection status.

⑮ **[ ] will be displayed when password is required for the connection.** (See page 29)

⑯ **Connection message**
Blinks when connection is not possible. Click to display information on resolving the issue. (See page 22)

⑰ **The [Projector Name] of the selected projector and the name given in the favorites are displayed (See page 49).**
Guides for the operating status and connection method etc are also displayed.

⑱ **Connectability**
The name and ID of projectors are displayed on the upper left of the selected projector's projection screen.
Once it is confirmed as connectable, the message "Projector is available." will appear on the PC screen.

⑲ **Connection**
Connect to the selected projector.

※1
- In the following situations, connections other than [U (user)] are not possible.
  - Not logged in with Administrator authority
- Depending on the computer and wireless LAN adapter used, Easy Wireless Set Up may not be possible. If this is the case, the [Network] number of <Projector Search> window automatically switches to [U (user)]. For details of the connection procedure, first close Wireless Manager ME 5.5, and then refer to pages 25 - 27.

※2
- The network number is [S-MAP], when Wireless Manager ME 5.5 starts. These numbers must match for the connection. To check the network number, refer to the network menu of the projector.
- When importance is placed on security, select the network number [2] - [4], because WEP (wireless communication encryption)※ is set on these network numbers.
- If [U (user)] is used for the network number, important video/audio data is protected because AES※ encryption processing takes place in advance for all network numbers, even though [ENCRYPTION] is set to [NONE].
- Other network adapters may not be usable under Easy Wireless Set Up connections.
- Connections to other networks connected through the wireless LAN adapter are broken under Easy Wireless Set Up connections.

※ "Glossary" (See page 71)

Connecting with wireless LAN (cont.)

“S-MAP” Connection

1 Click [ ] on the desktop.

Alternatively, select [Start] → [All Programs] → [Panasonic Wireless Display] → [Wireless Manager mobile edition 5.5].



<Projector Search> window – [S-MAP] is displayed. (Parts name → See page 15)

- **When the <Input User Name> window appears**
  Set the icon and user name, and click [OK].

Notes

- The icon and user name are set when Wireless Manager mobile edition 5.5 is first launched.
- The icon and user name settings can be changed in the <Option> window. (See page 50)

2 Select and click the icon [ ] of the projector you want to connect to.

(represents the projectors that were searched and found through wired LAN, while indicates those found through wireless LAN.)
The Connect/Connectability menu is displayed.
For List Display, [ ] is displayed in the selected projector.
(In list view, select a projector you want to connect from the list and press [Connect].)

<Projector Search> Window – [S-MAP]



<Projector Search> Window – [S-MAP] (List display)



3 Select and click [Connect].

- **If the <Confirmation Dialog> box is displayed**
  Click [Yes(Y)].


Wireless Manager
Wireless Select
Wireless Adapter is currently connected to the Network. Is it OK to switch to Projector Network?
YES(Y)
NO(N)

Notes

- For details on how to connect, refer to page 50.
- Refer to the models on page 47 supporting the wired LAN that is compatible with this software.
- If you want to enable the network adapter after starting the Wireless Manager, you should do it after exiting the Wireless Manager.

4 Connection completed.

When the connection with the projector is established, the launcher appears. (“Description of the launcher”→ See page 32)

Notes

- The “Signal strength level” is just a guide. As differences occur due to conditions such as the communication environment, this does not always display accurate values.
- Enter the user name in up to 8 alphanumerics.
- The launcher is not projected on the projector. However, if you are using Windows Vista or Windows 7, the installed launcher is projected.
- If you cannot connect the projector and computer using Easy Wireless Setup (See page 72).
- If you do not find a projector you want to connect, press [Update] button.
- When a firewall is active, a window may open prompting to deactivate a network block. (See screen ① on page 75.)
- When a network connection is established by using the connection utility, a window may open prompting to halt the connection utility. (See screen ② on page 76.)

Connecting with wireless LAN (cont.)

"1-4/U" Connection

1 **Click [ ] on the desktop, or select [Start] → [All Programs] → [Panasonic Wireless Display] → [Wireless Manager mobile edition 5.5].**

<Projector Search> window – [S-MAP] is displayed.



- **When the <Input User Name> window appears**
  Set the icon and user name, and click [OK].

Notes

- The icon and user name are set when Wireless Manager ME 5.5 is first launched.
- The icon and user name settings can be changed in the <Option> window. (See page 50)

2 **Click [1-4/U] from the setting menu.**

If the setting menu is not displayed, click [Setting ▶].

- **When the <Confirmation dialog> box appears**
  Click [YES (Y)].


Wireless Manager
Wireless Select
Wireless Adapter is currently connected to the Network. Is it OK to switch to Projector Network?
YES(Y)
NO(N)

Notes

- Refer to the models on page 47 supporting the wired LAN that is compatible with this software.
- If you want to enable the network adapter after starting the Wireless Manager, you should do it after exiting the Wireless Manager.

3 **A list of projectors that can be connected to are displayed in the <Projector Search> window – [1-4/U].**



4 **Select the same Network number as the [Network number] for the projector you want to connect to (see page 53).**

Projectors powered on in the chosen network group are listed.

5 **Select the desired projectors, and click [Connect].**

The launcher appears and the connection with the projector is established. ("Description of the launcher" → See page 32)

Notes

- Enter the user name in up to 8 alphanumerics.
- The launcher is not projected on the projector. However, if you are using Windows Vista or Windows 7, the installed launcher is projected.
- If you cannot connect the projector and the computer using Easy Wireless Setup (See page 72).
- If you do not find a projector you want to connect, press [Update] button.
- You can search through all the network numbers from 1 through 4, if you select [All].
- When a firewall is active, a window may open prompting to deactivate a network block. (See screen ① on page 75.)
- When a network connection is established by using the connection utility, a window may open prompting to halt the connection utility. (See screen ② on page 76.)

Connecting with wireless LAN (cont.)

"PC Search" Connection

1 **Click [ ] on the desktop, or select [Start] → [All Programs] → [Panasonic Wireless Display] → [Wireless Manager mobile edition 5.5].**

<Projector Search> window – [S-MAP] is displayed.

- **When the <Input User Name> window appears**

  Set the icon and user name, and click [OK].



Notes

- The icon and user name are set when Wireless Manager ME 5.5 is first launched.
- The icon and user name settings can be changed in the <Option> window. (See page 50)

2 **Click [PC Search] from the setting menu.**

If the setting menu is not displayed, click [Setting ▶].



- **When the <Confirmation dialog> box appears**

  Click [YES (Y)].


Wireless Manager
Wireless Select
Wireless Adapter is currently connected to the Network. Is it OK to switch to Projector Network?
YES(Y)
NO(N)

Notes

- Enter the user name in up to 8 alphanumerics.
- If you want to enable the network adapter after starting the Wireless Manager, you should do it after exiting Wireless Manager.
- When a firewall is active, a window may open prompting to deactivate a network block. (See screen ① on page 75.)
- When a network connection is established by using the connection utility, a window may open prompting to halt the connection utility. (See screen ② on page 76.)

Connecting with wireless LAN (cont.)

3 Select the projector to connect.

<PC Search> window appears.


Wireless Manager
Current setting > - [Single] - [PCSearch]
Setting
S-MAP
1-4/U
PCSearch
Select the computer to connect from the projector.
1. Turn on the projector power.
2. Press the [ ] button on the remote control.
3. Please select user name [UserName] from list.
Close

Note

Click on [i] in the <PC Search> window, and the models of projector that can perform [PC Search] are displayed. (See page 47)

■Operations on the projector

① Turn on the power to the projector unit.
② Press the [COMPUTER SEARCH] button on the remote control.
(You can also search from [COMPUTER SEARCH] from the network menu.
→ See page 58)
The computers that can be connected to the projector are displayed in a list.
③ Select from the list displayed on the projector an item with the same icon/ user name as is displayed on the computer <PC Search> screen.



4 Connection completed.

When the connection with the projector is established, the launcher appears.
(“Description of the launcher” → See page 32)

Note

The launcher is not projected on the projector.
However, if you are using Windows Vista or Windows 7, the installed launcher is projected.

Connecting with wireless LAN (cont.)

Connection error messages

If wireless LAN is not available, [i] will blink in lower left corner of the <Projector Search> window ([S-MAP] or [1-4/U]).



Click the [i] button at this time to display information on resolving the issue as shown below.



Click the [Detail] button to display detailed information.
Note that the [Detail] button is available only when the Firewall/ Connection Utility is found active.
To perform the selected Firewall/Connection Utility process every time, check [The operation is always performed from next time.]. This message will no longer be displayed from the next time the software is launched. If you want to display the message when the software is launched, check the corresponding item of <Firewall/Wireless LAN Utility Message> on the [Other2] tab of [Option]. (See page 50)


Wireless Manager
Confirmation message
Firewall
Windows Firewall
Cisco VPN Service
A firewall was found.
To search for projectors and to connect, the firewall must be unblocked or stopped temporarily.
The state of the firewall is restored when quitting WirelessManager.
The following action(s) will be applied to the selected firewall:
- Unblock Windows firewall
- Stop Cisco VPN Service
The operation is always performed from next time.
O K
Cancel

The displayed information is as follows.

Detected issue	Displayed information	Remarks	Reference page
A firewall or network bridge is detected	[****]※ is installed. When destination cannot be identified, deactivate [****] which is the cause.	• Has your firewall in Windows XP been disabled? • Is Wireless Manager mobile edition 5.5 registered in [Exceptions] ([Control Panel] → [Security Center] → [Windows firewall]) with the Windows XP SP 2? • Is this software registered in the [Exceptions] tab in [Control Panel] – [Windows Firewall] – [Allow program through Windows firewall] in Windows Vista? • Are any firewall-containing applications installed? • If you do not expect ever to use Network Bridge and see no need for it, delete it from your system. • Is this software registered in [Start] → [Control Panel] → [System and Security] → [Allow a program through Windows Firewall] in Windows 7?	P.73 - P.76

※ “Windows Firewall”, “Network Bridge” and other security software found will appear in [****].

Connecting with wireless LAN (cont.)

The displayed information is as follows.

Detected issue	Displayed information	Remarks	Reference page
When a change in the settings made by the utility has been detected	The settings of Wireless Network connection have been changed. When a Wireless LAN adapter utility or any other utilities are active, stop the operation of such utilities, then restart the Wireless Manager ME 5.5.	The wireless LAN adapter utility used by the computer may have changed the wireless settings. Close the utility, and then make the connection again using Easy Wireless Set Up connection.	–
When a setting error for the wireless LAN adapter has been detected	No response from the wireless LAN adapter. • Wireless LAN adapter conditions • Driver version (Latest)	• Is the wireless LAN adapter effective? • Is your wireless LAN adapter properly recognized? • Some wireless LAN adapters may allow Easy Wireless Set Up connections to function if drivers are updated.	P.72
When the user does not have the administrator authority	Please execute “Easy Connection” using the administrator authorization mode.	If you have logged in as a user that does not have administrator permission or as [GUEST], you cannot use easy wireless setup [S-MAP]/network numbers [1]-[4]. If you must perform Easy Wireless Set Up without administrator authority, designate [U (user)] as the network number.	P.25
Issues other than the above	Please perform the following checks, when the projector cannot be found. [Projector setup] (1) Is the power on for the projector? (2) Is the Network capability on? (3) Has the network channel number correctly been set up? [Computer setup] (1) Is Wireless capability on? (2) Is the Firewall application causing a network block? (3) Is wireless enabled?	• Is the power of the projector on? • Is the network capability of the projector ON? • Do the network settings of the projector and the network of Wireless Manager ME 5.5 match? • Is the wireless capability of the computer ON? • Is communication being blocked by a Firewall application installed on the computer? • Is wireless/wired enabled?	

Connecting through the access point

You can make the setting for infrastructure mode※ (connection through the access point※); however, confirm to your system administrator on network settings before changing any settings.
※“Glossary” (See pages 70 - 71)

① Projector settings

1 **Turn on the projector and press the [NETWORK] button on the remote control.**

2 **Press the menu button to open the [NETWORK] menu, and then select from among [USER 1] through [USER 3] for [WIRELESS LAN] and press [ENTER].**

3 **Set the details of network and select [OK].**
As for network setting items, see pages 53 - 55.
Confirm to your system administrator on network settings before changing any settings.

Note
The projector’s MAC address※ can be checked with [STATUS] in the network menu of the projector unit.
(“Verifying settings”→ See page 59) ※“Glossary” (See page 70)

② Computer settings

4 **Turn on the computer.**

5 **Make the network setting according to your system administrator.**

6 **Connect to your access point.**

7 **Start Wireless Manager ME 5.5.**
A confirmation message appears asking whether to switch the projector to the network or not. Select [No].

8 **Select a projector you want to connect on the <Projector Search> window ([S-MAP] or [1-4/U]), and click [Connect]. (See pages 18, 19)**
The launcher appears and the connection with the projector is established.
(“Description of the launcher” → See page 32)

Note
If no projector is displayed, click [ ] to start searching by IP address. (See page 29)

Note
If you cannot establish wireless LAN connection via an access point after performed the right steps described in “① Setting projector”, contact the manufacturer of your access point (i.e. radio relay device).

Connecting with wireless LAN (cont.)

When logging on without administrator authority

Before getting started Wireless Manager ME 5.5, the PC's IP setting must be set to [Acquire IP address automatically]. Before use, contact your network administrator to make sure the proper setting.

① Projector settings

1 **Turn on the projector and press the [NETWORK] button on the remote control.**

2 **Press the menu button to open the [NETWORK] menu, and then select from among [USER 1] through [USER 3] for [WIRELESS LAN] and press [ENTER].**

3 **In wireless LAN detailed setting 1/3, turn off [DHCP※], configure [IP address※], [SUBNETMASK※], and [DEFAULT GATEWAY※], and then click [NEXT].**

<Example>



※“Glossary” (See page 70)

Notes

- Wireless LAN and wired LAN cannot be used in the same segment.
- When multiple devices are connected, a unique IP address must be allocated to each device.

4 **In wireless LAN detailed setting 2/3, enter [SSID※] and set [MODE] to [AD HOC※], and then click [NEXT].**

<Example>



※“Glossary” (See page 71)

Notes

- SSID has to be entered in lower-case alphanumeric letters.
- See pages 53 to 55 for information on other network settings.

5 **Press [OK] in wireless LAN detailed setting 3/3.**

Connecting with wireless LAN (cont.)

② **Computer operation (For Windows XP)**

6 Log on with the user who operates Wireless Manager ME 5.5.

7 Click [Start], [Network Connections], [Wireless Network Connection] and select the wireless network for which you have specified [SSID] in step 4, and then click [Connect].

<Example>
When using Windows [Wireless Network Connection] to connect with the projector whose [SSID] is [Panasonic Projector]


Wireless Network Connection
Network Tasks
Refresh network list
Set up a wireless network for a home or small office
Related Tasks
Learn about wireless networking
Change the order of preferred networks
Change advanced settings
Choose a wireless network
Click an item in the list below to connect to a wireless network in range or to get more information.
Panasonic Display3
Security-enabled computer-to-computer network
Panasonic Display4
Security-enabled computer-to-computer network
Panasonic Display2
Security-enabled computer-to-computer network
Panasonic Projector
Unsecured computer-to-computer network
This network is configured for open access. Information sent over this network may be visible to others. If you want to connect to this network, click Connect.
PD11568646109Name15680A01025C
Connect

Note

If you use any wireless utility other than Windows [Wireless Network Connection], follow its operation procedure for connection.

8 Start Wireless Manager ME 5.5.

9 Select a projector you want to connect on the <Projector Search> Window ([S-MAP] or [1-4/U]), and click [Connect]. (See pages 18, 19)



- For information on how to confirm the projector you want to connect, refer to [Search by ID] in [Other search] section on page 29.
- The launcher appears and the connection with the projector is established. (“Description of the launcher” → See page 32)

Connecting with wireless LAN (cont.)

② Computer operation (For Windows Vista)

6 **Log on with the user who operates Wireless Manager ME 5.5.**

7 **Click [Start] and [Connection], and select the wireless network for which you have specified [SSID] in step 4, and then click [Connect].**

<Example>
When using Windows [Network Connection] to connect with the projector whose [SSID] is [Panasonic Projector]



Note

If you use any wireless utility other than Windows [Wireless Network Connection], follow its operation procedure for connection.

8 **Start Wireless Manager ME 5.5.**

9 **Select a projector you want to connect on the <Projector Search> Window ([S-MAP] or [1-4/U]), and click [Connect]. (See pages 18, 19)**

For information on how to connect with projectors, refer to item 9 in [② Computer operation (For Windows XP)] section. (See page 26)

② Computer operation (For Windows 7)

6 **Log on with the user who operates Wireless Manager ME 5.5.**

7 **Click [Start] and [Connection], and select the wireless network for which you have specified [SSID] in step 4, and then click [Connect].**

<Example>
When using Windows [Open Network and Sharing Center] to connect with the projector whose [SSID] is [Panasonic Projector]



Note

If you use any wireless utility other than Windows [Wireless Network Connection], follow its operation procedure for connection.

8 **Start Wireless Manager ME 5.5.**

9 **Select a projector you want to connect on the <Projector Search> Window ([S-MAP] or [1-4/U]), and click [Connect]. (See pages 18, 19)**

For information on how to connect with projectors, refer to item 9 in [② Computer operation (For Windows XP)] section. (See page 26)

Connecting with Wired LAN

Connection can be made with wired LAN. However, confirm to your system administrator on network settings before changing any settings.

① Projector settings

1 **Turn on the projector and press the [NETWORK] button on the remote control.**

2 **Press the menu button to open the [NETWORK] menu, select [Wired LAN] and then press [OK].**

3 **Set the details of network and select [ENTER].**

As for network setting items, see page 52.
Confirm to your system administrator before changing any settings.

② Computer settings

4 **Turn on the computer.**

5 **Make the network setting according to your system administrator.**

If the projector settings are the default settings (See page 52), then the computer can be used with the following network settings.

IP ADDRESS	192.168.10.101
SUBNETMASK	255.255.255.0
DEFAULT GATEWAY	192.168.10.1

6 **Launch Wireless Manager ME 5.5**

7 **Select a projector you want to connect on the <Projector Search> window ([S-MAP] or [1-4/U]), and click [Connect]. (See pages 18, 19)**

When the connection with the projector is established, the launcher appears.
(“Description of the launcher” → See page 32)

Note

If no projector is displayed, click [ ] to start searching by IP address. (See page 29)

Other operations for connection

Operations when password entry is required for connection

A [🔒] mark is displayed for projectors that have passwords set.
The window shown to the right appears to establish a connection. Enter the password for the projector and click [OK].
(Password setting → See page 56)



Notes

- Click [CANCEL] at the <Password Input> window to return to launcher canceling the connection. (See page 32)
- When an incorrect password is entered, an error message appears.
  Click [OK] to return to the <Password Input> window and enter the correct password again.

Other search

Apart from “Easy Wireless Set Up” (See page 15), there are 3 other ways to search for and connect to a projector, namely “Search by IP address”, “Search by domain name”, and “Search by ID”.
These methods can be used if you cannot search using “Easy Wireless Set Up”.

- Search by IP address — Search for and connect to a projector from the IP address※.
  The projector that you want to connect to must have a network number of [USER1]-[USER3] and must have the IP address set. (See pages 52, 53)
- Search by domain name — Search for and connect to a projector from the domain name※.
  The projector that you want to connect to must have a network number of [USER1]-[USER3] and must have the IP address set. (See pages 52, 53)
  ※ “Glossary” (See page 70)
- Search by ID — Even if there are two or more projectors with the same name, an ID ([Proj] + 4-digit number) is assigned to each projector to enable the projectors to be identified.
  A search for the projector of the specified ID is carried out from among the projectors that are presently switched on, from all network numbers other than [USER1]-[USER3].
  It is necessary to know ID in advance. When input selection is switched to [NETWORK] on a projector, the ID appears on the upper right of the projection screen for approximately 5 seconds. If you write down the ID displayed in the [ID] column of the <Projector Search> window in advance, you can search a projector by the ID from next time.

1 Click [🔍] at the <Projector Search> window.

<Other search> window appears.



2 Enter the information of the projector you want to search for, and select the search criteria.

- When using “Search by IP address”
  ① Enter the IP address (including its periods).
  Example: 192.168.10.100
  ② Select [Search by IP address]
- When using “Search by domain name”
  ① Enter the domain name.
  ② Select [Search by domain name].
- When using “Search by ID”
  ① Enter the ID.
  ② Select [Search by ID].

Other operations for connection (cont.)

3 Click [Search].

When <Other search> window – [Searching] is displayed, the search starts.



4 Check the search results.

When the projector of the applicable ID is found, the [Projector Name] and [ID] appear.

Note

If a projector of the applicable ID is not found, [No Projector detected.] appear.



5 Click [Connect].

When the connection with the projector is established, the launcher is displayed.
(“Description of the launcher” → See page 32)

Note

The launcher is not projected by the projector.
However, if you are using Windows Vista or Windows 7, the installed launcher is projected.

Automatic connection by “One-click connection”

An automatic connection can be established using the created profile.
This function is called “One click connection.” (Create a profile → See page 31)

Perform step ① or ②.

① Double-click the profile.
(This function cannot be used when using without installation.)
② Drag and drop the profile to the [] on the desktop.
The computer connect to the projector that was connected when the profile was created.

Other operations for connection (cont.)

Exit Wireless Manager

1 Click [ ] on the launcher.

The following window appears.



■ When connecting the projector for the first time

The <Preservation of a Profile> window appears.
Create a profile with information about connected projectors.
You can use the created profile to connect automatically.
This function is called “One-click Connection”. (One-click Connection → See page 30)

Set the save destination and file name, and click [OK].
If you do not need to create a profile, click [Close].



2 Click [Yes].

The computer returns to the original network settings when the connection is ended.
However, note that some time may be needed to return to the original network settings.
Click [No] to return to the launcher.

Notes

• When the launcher is minimized, right click [ ] on the notification area to display pop up menu and click [End].
• You can also exit by selecting [End] from the launcher menu.

Various projection methods

Description of the launcher

The launcher always appears on the computer screen, and can be used to perform various operations.
- If the launcher has been minimized to the task tray, right click the [ ] icon to display the launcher menu and operate the launcher.
- To return the launcher from the task tray, double-click the [ ] icon, or select “Display menu bar” from the menu.
- The launcher can be dragged to any position in the screen.



■ Status indication

① **Status**: Indicate the connecting status.
When the cursor is moved to the launcher, the names, IDs, and statuses of the connected projectors are displayed in a pop up window.



When connected to one projector

- (Green, lit): Transmission possible
- (Blue, lit): Own computer currently transmitting (when in live mode)
- (Yellow, lit): Other user currently transmitting
- (Red, lit): Communication impossible
- (Black, lit): When the projector has not been selected

When connected to multiple projectors

- (Green, lit): All transmission possible
- (Blue, lit): Currently Transmitting
- (Yellow, lit): Communication impossible for more than one unit
- (Red, lit): All communication impossible
- (Black, lit): When the projector has not been selected

② **Reception strength level:** Displays the strength level condition of the reception. The more bars displayed, the stronger the reception and the better the communication environment.

Notes
- The display configuration (direction) of the launcher may vary depending on the locations on the screen.
- The reception strength level may not be displayed correctly depending on the computer you are using.

Various projection methods (cont.)



■ Operating Button

① **Launcher menu button**: The launcher menu will appear. You can operate it by clicking the various items.

[Start/Pause]:	Starts/pauses projecting.
[Stop]:	Stops projecting.
[Live Mode]:	The live mode menu will appear. Set a projection position for live mode. (See pages 34 - 35)
[Selective Area Transmission]:	By using the selective area window, you can specify the necessary information alone from the computer screen, and display it on the projection screen. (See page 44)
[Display Change]:	You can set the computer screen and projector screen to the multi-monitor mode, and use the computer screen as the primary monitor and projector screen as a secondary monitor. (See page 45)
[Virtual Remocon]:	The projector remote control is displayed on the computer screen, where it can be operated.

[Pointer]:	Switches the pointer shape on the projected screen. (See page 46)
[AV Mute]:	Temporarily mutes the projector screen and volume. (See page 46)
[WEB control]:	Control a projector through the WebBrowser of a computer. (See page 60)
[Select Access Port]:	The <Projector Search> window ([S-MAP], [1-4/U], [PC search]) appears. (See pages 18, 19, 21)
[Option]:	Displays the <Option> window. (See page 48)
[About Wireless Manager]:	The version information on Wireless Manager ME 5.5 appears.
[Display Menu Bar]:	Displays the launcher menu. (When minimized into the task tray.)
②**Favorite function button:**	You can set the function you use frequently to this button. (See page 50)
③**Stop projection button:**	Stops projecting.
④**Projection start button:**	Starts projection. During transmission, the display changes to [ ] (paused).
⑤**Volume Adjust Button:**	The volume control slider and mute button are displayed. Click again to close.

Note

For the projectors equipped with the 2 screen function, it can be used by means of the virtual remote control.

Various projection methods (cont.)

Live Mode

Connect a computer to a projector, and display the computer screen over the entire projection screen.
(If the connection is completed, and input is via network.)

1 Press the [MULTI-LIVE] button on the remote control to turn the projection screen into a full screen display (the status when no index window (small screens) is displayed). (See page 35)

If you press the [MULTI-LIVE] button once or twice when index windows are displayed on the projection screen, the screen will switch over to a full screen display.

Note

Full screen mode is not available in live mode when an index window is displayed.

2 Check the status indication on the launcher to make sure that transmission is possible ( ). (See page 32)

3 Click [ ].

The launcher menu will appear.



4 Click [Live Mode] in the launcher menu.

5 Click [All].



6 Click [ ] on the launcher.

The current computer screen is transmitted to the selected projector. In the live mode the projector is occupied by a single computer, so operations from other computers are not possible.

Notes

- Picture quality or other options can be set on the <Option> window by clicking [Option] in the launcher menu. (See page 48)
- For presentations in live mode, the [PAGE ▲▼] buttons on the remote control will function in the same way as the computer's Page Up and Page Down keys. (The buttons correspond to Back space key and Space key only for "Presenter mode" of Microsoft Office PowerPoint (hereinafter called PowerPoint).) You can switch the presentation screen using the remote-controller, if an application program is active on the PC that supports the Page Up/Page Down keys.
- Some portions of images are not projected under some applications (Microsoft Office Assistant, IME Bar, animation and locus of the mouse cursor, and others).
- If the connection error occurs during projection, the message ["Live mode" is deactivated] will appear. Check the communication environment, then restart projection by clicking launcher buttons.
- Set the [LIVE MODE CUT IN] of the unit to [ON] in advance to enable a different computer to interrupt and project images in live mode. (See page 58)

■Quitting live mode

Click [ ] on the launcher.

Various projection methods (cont.)

Multi Live Mode

Switching from one style to another

Multi live mode has “4-screen multi style”, “4-screen index style” and “16-screen index style”.

■How to operate

Press the [MULTI-LIVE] button of the remote control to change the style.

- 4-screen multi style (See page 36)
  Set the projector to a full screen display. Assign an area of one quarter of the projector screen to each of up to four computers, and project images on the projector screen.
- 4-screen index style (See page 37)
  Display the indexes (small screens) of up to four computer screens, and make one of these screens an enlarged display. You can also temporarily switch over to a full screen display.
- 16-screen index style (See page 39)
  Display the indexes of up to 16 computer screens. You can also temporarily switch over one of these screens to a full screen display.



Notes

- When the projector starts up, it resumes in the current style the last time the projector was turned off.
- When transferring to the Live mode, first select the 4-screen multi style, and then click [▶] on the computer.
- If you switch over to a 4-screen multi style when five or more computers are connected in a 16-screen index style, the connections to the fifth and higher numbered computers will be nullified.
- You cannot use the “MULTI-LIVE” button on the remote control when in full screen display.

Various projection methods (cont.)

4-screen multi style

Connect up to four computers to one projector, and then divide the projector screen into four parts, and simultaneously display the screens for the four computers on the projector screen. (If the connection is completed, and input is via network.)

1 **Press the [MULTI-LIVE] button on the remote control to turn the projection screen into a full screen display (the status when no index window (small screens) is displayed). (See page 35)**

If you press the [MULTI-LIVE] button once or twice when index windows are displayed on the projection screen, the screen will switch over to a full screen display.

2 **Check the status indication on the launcher to make sure that transmission is possible ( ). (See page 32)**

3 **Click [ ].**

The launcher menu will appear.

4 **Click [Live Mode] in the launcher menu.**



5 **Select and click the projection position.**



6 **Click [ ] on the launcher.**

The computer image is transmitted to the selected quarter of the projection screen.

■Switching to a different position

Select and click a different projection position in step 4 above.

■Enlarged display

Click [Live Mode] and [ALL] from the launcher menu to display the PC screen onto the entire projection screen. To return to the original display, click [Live Mode] on the launcher and select original projection positions with each computer.

■Quitting 4-screen multi-live

Click [ ] on the launcher.

Notes

- In the 4-screen multi style, the computer screens from all the computers connected to the projector can be transmitted to the projector. (If an image from another computer has been sent to the image position where an image is already displayed, the existing image is replaced by the new image.)
- Picture quality or other options can be set on the <Option> window by clicking [Option] in the launcher menu. (See page 48)
- If the connection error occurs during projection, the message [“Live mode” is deactivated] will appear. Check the communication environment, then restart projection by clicking launcher buttons.

Various projection methods (cont.)

4-screen index style

When the projector is set to “4-screen index style”, connect up to 4 computers to one projector, and then simultaneously display the screens for the 4 computers on the index windows and also on a large screen.
(If the connection is completed, and input is via network.)

1 **Press the [MULTI-LIVE] button of the remote control to switch the projection screen to “4-screen index style”. (See page 35)**

2 **Check the status indication on the launcher to make sure that transmission is possible ( ). (See page 32)**

3 **Click [ ].**
The launcher menu will appear.



4 **Click [Live Mode] in the launcher menu.**

5 **Select and click the projection position.**



6 **Click [ ] on the launcher.**
The computer image is transmitted to the area of corresponding window.



Various projection methods (cont.)

■Enlarged display





- Use the [◀ ▶] buttons on the remote control to move the focus (yellow box) to the image to be enlarged, and press the [ENTER] button. The image is enlarged and displayed at the top of the projection screen.
- The image display will fill the entire screen if the [ENTER] button is pressed again.



- To return to the 4-screen index style, press the [ENTER] button again.

Notes

- While an enlarged image is displayed, the [PAGE ▲▼] buttons on the remote control will function in the same way as the computer's Page Up and Page Down keys. (When using "Presenter View" of "PowerPoint", the [PAGE ▲▼] buttons of the remote control correspond to Back space key and Space key.) This means that if you run a computer application that supports the Page Up and Page Down keys, the presentation screen can be changed using the remote control.
- Picture quality or other options can be set on the <Option> window by clicking [Option] in the launcher menu. (See page 48)
- If the connection error occurs during projection, the message ["Live mode" is deactivated] will appear. Check the communication environment, then restart projection by clicking launcher buttons.
- Depending on the model, use the [▲▼] buttons on the remote control to move the focus (yellow box).

■Quitting the 4-screen index style projection

Click [ ] on the launcher.

Note

In the 4-screen index style, the status display lamp remains lit green ( ). Other computers can send images only to the windows which are not being used.

Various projection methods (cont.)

16-screen index style

When the projector is set to “16-screen index style”, connect up to 16 computers to one projector, and simultaneously display the screens for the 16 computers on index windows and also on a large screen.
(If the connection is completed, and input is via network.)

1 **Press the [MULTI-LIVE] button of the remote control to switch the projection screen to “16-screen index style”. (See page 35)**

2 **Check the status indication on the launcher to make sure that transmission is possible ( ). (See page 32)**

3 **Click [ ] on the launcher.**

The computer images are automatically sent to the empty windows on the 16-screen display.
Display position is not selectable.

■Enlarged display

- Use the [◄►▲▼] buttons on the remote control to move the focus (yellow box) to the image to be enlarged and press [ENTER] to expand that image to fill the display.
- Press [ENTER] again to return to the 16-screen index style.



Notes

- While an enlarged image is displayed, the [PAGE ▲▼] buttons on the remote control will function in the same way as the computer’s Page Up and Page Down keys. (When using “Presenter View” of “PowerPoint”, the [PAGE ▲▼] buttons of the remote control correspond to Back space key and Space key.) This means that if you run a computer application that supports the Page Up and Page Down keys, the presentation screen can be changed using the remote control.
- Picture quality or other options can be set on the <Option> window by clicking [Option] in the launcher menu. (See page 48)
- If the connection error occurs during projection, the message [“Live mode” is deactivated] will appear. Check the communication environment, then restart projection by clicking launcher buttons.

■Quitting the 16-screen index style projection

Click [ ] on the launcher.

Various projection methods (cont.)

Multiple Source Live Mode

You can simultaneously project one computer's screen on up to eight projectors.

Notes

Projection can be provided for the projector having the same network number of either "1" through "4" or "USER1" through "USER3"

1 **Press the [MULTI-LIVE] button on the remote control to turn the projection screen into a full screen display (the status when no index window is displayed). (See page 35)**

If you press the [MULTI-LIVE] button once or twice when index windows are displayed on the projection screen, the screen will switch over to a full screen display.

2 **Click [ ].**

The launcher menu will appear.



3 **Click [Select Access Port] in the launcher menu.**

(When controlling multi-live in the search screen)

4 **Click [1-4/U] from the setting menu.**

<Projector Search> window – [1-4/U] is displayed.
If the setting menu is not displayed, click [Setting ►].

5 **Click [ ].**

6 **Select the network number of the desired projectors. (See page 53)**

Projectors powered on in the chosen network group are listed.



7 **Select the desired projectors, and click [Connect].**

The selected projector is displayed with a blue-colored [ ].
If click again, selected items are canceled.
If click [Connect], the connection with the projectors is established.



8 Check the status indication on the launcher to make sure that transmission is possible ( ). (See page 32)

9 Click [ ] on the launcher.

The same image is projected from all projectors selected in step 7.

Notes

- Projection is provided in multi-live mode for the projector having the same network number that is selected in PC.
- Among the selected projectors, if there is one to which other PC is transmitting data or of which the projection screen is not set to full-screen, projection is provided for that one.
- The greater the number of projectors, the slower the transmission.
- Picture quality or other options can be set on the <Option> window by clicking [Option] in the launcher menu. (See page 48)
- Sound cannot be output in the multiple source live mode.
- If the connection error occurs during projection, the message [“Live mode” is deactivated] will appear. Check the communication environment, then restart projection by clicking launcher buttons.
- Set the [LIVE MODE CUT IN] of the unit to [ON] in advance to enable a different computer to interrupt and project images in live mode. (See page 58)

■Quitting multiple source live mode

Click [ ] on the launcher again.

Various projection methods (cont.)

Multiple Source Multi Live Mode

Up to 4 computers are connected to the maximum of 8 projectors; each projector provides 4-screen multi-style view.

Note

Can be projected by projectors that have a network number of [1]-[4] or [USER1]-[USER3].

1 **Press the [MULTI-LIVE] button on the remote control to turn the projection screen into a full screen display (the status when no index window is displayed). (See page 35)**

If you press the [MULTI-LIVE] button once or twice when index windows are displayed on the projection screen, the screen will switch over to a full screen display.

2 **Click [ ].**

The launcher menu will appear.



3 **Click [Select Access Port] in the launcher menu.**

(When controlling multi-live in the search screen)

4 **Click [1-4/U] from the setting menu.**

<Projector Search> window – [1-4/U] is displayed.
If the setting menu is not displayed, click [Setting ►].

5 **Click [ ].**

6 **Select the network number of the desired projectors. (See page 53)**

Projectors powered on in the chosen network group are listed.



7 **Select the desired projectors, and click [Connect].**

The selected projector is displayed with a blue-colored [ ].
If click again, selected items are canceled.
If click [Connect], the connection with the projectors is established.



Various projection methods (cont.)

8 **Check the status indication on the launcher to make sure that transmission is possible ( ). (See page 32)**

9 **Click [ ].**
The launcher menu will appear.



10 **Click [Live Mode] in the launcher menu.**

11 **Select and click the projection position.**



12 **Click [ ] on the launcher.**
The computer image is transmitted to the selected quarter of the projection screen.

■Switching to a different position
Select and click a different projection position in step 11 above.

■Enlarged display
If [Live Mode] – [All] are clicked in the launcher menu, projector screens temporarily change to full screen display. To return to the original display, click [Live Mode] on the launcher and select original projection positions with each computer.

■Secondary viewer function
If another computer switches to the enhanced view, your screen will disappear from the projection screen while your are using the secondary display transmission feature; however, it is displayed as a secondary viewer on computer screen. (See page 45)

■Quitting multiple source multi live mode
Click [ ] on the launcher.

Notes
- From the selected projectors, multiple projectors that have the same network number are projected in multi-live mode.
- If LB20NT/30NT or a projector whose projection screen is not set to full screen display is included among the selected projectors, the launcher live mode [1]-[4] will be grayed out, preventing the projector from being selected.
- The greater the number of projectors, the slower the transmission.
- In multiple source multi live mode even when the remote projector [MULTI-LIVE] button is pressed no operation will result.
- Picture quality or other options can be set on the <Option> window by clicking [Option] in the launcher menu. (See page 48)
- If the connection error occurs during projection, the message [“Live mode” is deactivated] will appear. Check the communication environment, then restart projection by clicking launcher buttons.

Useful Functions

Selective Area Transmission

By using the selective area window, you can specify the necessary information alone from the computer screen, and display it on the projection screen.

1 Click [ ].

The launcher menu will appear.



2 Click [Selective Area Transmission] in the launcher menu.

The range selection screen is displayed.

3 With the left mouse button held down, surround the area you want to send to the projector.

Selective area window (green) appears on computer screen.
You can perform operations in the selective area window with the same operation for moving or changing the window on the computer screen.

- If clicking [ ], automatically determine the size of selected area and enclose it with a framework.
- If clicking [ ], the selective area window changes to its default size.
- If clicking [ ], the selective area transmission function ends.



Note

If you have drawn a straight line, a selective area window is displayed in the diagonal direction from your line.

4 Check the status indication on the launcher to make sure that transmission is possible ( ). (See page 32)

5 Click [ ] on the launcher.

The picture in the selective area window is projected.

Notes

- The picture inside the selective area window is displayed as big as possible with keeping the original aspect ratio to be fit for the resolution of projection screen.
- If you use Wireless Manager as a [Standard User] of Windows Vista or Windows 7 in the [Installation free set up] condition, the selective area transmission feature is not available.

■Quitting selective area transmission

Click [Selective Area Transmission] on the launcher again, or click [ ] on the upper right of the selective area window.

Useful Functions (cont.)

Secondary display transmission

You can set the computer screen and the projector screen to the multi-monitor mode, and use the computer screen as the primary monitor and the projector screen as the secondary monitor.

1 **Click [ ].**
The launcher menu will appear.



2 **Click [Display Change] in the launcher menu.**
The window shown to the right appears.

3 **Click [Secondary].**



4 **Check the status indication on the launcher to make sure that transmission is possible ( ). (See page 32)**

5 **Click [ ] on the launcher.**
The PC's secondary screen is projected to the projector.

Notes

- Like the normal multi-monitor function, you can change the relative positions of the primary monitor (computer screen) and secondary monitor (projector screen) in the [Settings] tab in the [Screen Properties] window ([Start] →[Control Panel] → [Appearances and Themes] → [Screen]).
- It is impossible to send images to the secondary monitor by the selective area transmission (See page 44).
- If the computer has been set to the multi-monitor mode, the monitor for the display switch-over function will be displayed as the third monitor in [Display Properties] of Windows.
- Some moving image applications may not play moving images when you are using secondary display transmission in Windows Vista or Windows 7.

■Quitting secondary display transmission

Click [Primary] in step 2.

Secondary Viewer

If you are using secondary display transmission function and projecting a secondary monitor screen in multiple source multi live mode, once [Live Mode] – [All] is pressed on one of the computers, the full screen display from the computer will override all the rest, and it will no longer be possible to verify the secondary screens of the other computers on the projector screen(s).
In this case, the secondary screen that you were projecting will appear on your desktop as a secondary viewer in reduced form.
Also, while using the secondary display transmission in the 4-screen index style and the 16-screen index style, the secondary viewer appears.



Notes

- You can perform operations on the secondary monitor while observing the secondary viewer on the computer screen, however an image will not appear on the projection screen(s) until the projection screen(s) goes back to the original projection style.
- When the projector screen(s) return to its original status, the contents of the secondary viewer are displayed on the projection screen(s), and the secondary viewer is closed as well.

Useful Functions (cont.)

AV Mute function

Blanks the screen for a moment.

1 **Click [ ].**
The launcher menu will appear.



2 **Click [AV mute] in the launcher menu.**
The image is turned off.
Audio output also goes out.

3 **Click [AV mute] in the launcher menu again.**
[AV mute] is disengaged.

Note
The AV mute Function is available only in live mode or multiple source live mode.

Pointer function

You can change the shape of the Pointer appearing on the projection screen in live mode or multiple source live mode to one that can be used for presentation purposes.

Click [Pointer] in the launcher menu.

■Quitting Pointer function

Click [Pointer] in the launcher menu again.

Useful Functions (cont.)

List of connectable projectors/available functions in each projection method

Wireless Manager ME 5.5 can be used when connected to the following projectors.

■ Connectable projectors

Projector	Easy setup			Network Adapter		PJLink™	Web control※	Mail function	Command control
	S-MAP	1-4/U	PC search	Wired LAN	Wireless LAN				
PT-F300NT/PT-FW300NT	✓	✓	✓	✓	✓	✓	✓	✓	✓
PT-F300/PT-FW300	×	×	×	✓	×	✓	✓	✓	✓
PT-LB90NT	✓	✓	✓	✓	✓	✓	✓	✓	✓
PT-LB80NT/PT-LW80NT	✓	✓	✓	×	✓	×	✓	×	×
PT-F200NT/PT-F100NT/PT-FW100NT	×	✓	✓	✓	✓	✓	✓	✓	×
PT-LB51NT	×	✓	✓	×	✓	×	✓	×	×
TH-LB50NT/TH-LB55NT/TH-LB60NT	×	✓	✓	×	✓	×	✓	×	×
TH-LB20NT/TH-LB30NT	×	✓	×	×	✓	×	✓	×	×

✓= Yes, ×= No

Note

The displayed screen, name and operation vary depending on the type of projectors. For detailed setting, see the operation manual for your projector.

※ The functions that can be operated differ depending on the projector you are using.

■ List of available functions in each projection method

When using PT-F300NT/PT-FW300NT/PT-F300/PT-FW300/ PT-LB90NT/PT-LB80NT/PT-LW80NT/PT-F200NT/PT-F100NT/ PT-FW100NT/PT-LB51NT/TH-LB50NT/TH-LB55NT/TH-LB60NT		Selective area transmission	Secondary display transmission	AV mute	Pointer
When connected to one projector	Live Mode	✓	✓	✓	✓
	Multi Live Mode	✓	✓	×	×
When connected to multiple projectors	Multiple Source Live Mode	✓	✓	✓	✓
	Multiple Source Multi Live Mode	✓	✓	×	×

When using TH-LB20NT/LB30NT		Selective area transmission	Secondary display transmission	AV mute	Pointer
When connected to one projector	Live Mode	×	✓	✓	✓
	Multi Live Mode	×	✓	×	×
When connected to multiple projectors	Multiple Source Live Mode	×	✓	✓	✓
	Multiple Source Multi Live Mode	—	—	—	—

✓= Yes, ×= No

Notes

- Sound can be output only in live mode. (See page 48)
- Sound is not output when multiple projectors are connected.

Setting options

You can make various settings related to Wireless Manager ME 5.5.

Setting options

1 **Click [ ].**
The launcher menu will appear.



2 **Click [Option] in the launcher menu.**
The <Option> window shown to the right appears.

3 **Click the desired tab to be set.**

4 **Click [OK].**



Transmission

■Resolution

Select the quality of the image transmitted from the computer to the projector.

- [Normal]
  This gives priority to speed when in live mode.

- [High Picture Quality (Performance is affected)]
  This gives priority to picture quality when in live mode.

■Live Mode Settings

- [Remove Image when shutting down Live Mode.]
  Set this if you want to make images on the projector cleared at the end of live mode.

- [Disable Screen Saver]
  This disables the computer screen saver function while Wireless Manager ME 5.5 is operating. Check this box to disable screen saver operation during live mode.

- [Display sender's name in Multi Live Mode]
  The characters (max. 8) which have been entered are displayed at the upper right of the transmitted screen.
  In the 4-screen and 16-screen index style modes, they are also displayed at the bottom of each image.
  (Alphanumerics are not displayed when the check mark has been removed.)

- [Produce audio along with video during Live Mode]
  You can set this when you want to output audio data from a projector in live mode.
  Also, volume setting operated from the launcher is different from the Windows' volume setting, and it is effective only for wireless connection. When finishing Wireless Manager ME 5.5, the Windows' volume setting becomes active.
  Sound can be output only in live mode.

- [Start Live Mode at the same time as connection]
  Projection starts when the connection is made without having to click the live button.

Note

In the initial settings, [Disable Screen Saver] is enabled. Please remember that the password protected screen saver is disabled if you need to leave your computer.

Setting options (cont.)

Key setting

You can set shortcut key combinations that let you control the Wireless Manager ME 5.5 functions by computer keyboard operations.

1 **Select the mode or the function to be set for the shortcut key, and click it.**

2 **Select one from [Ctrl], [Alt], and [Shift].**

3 **Select one alphabet to be used with the key chosen in step 2.**

4 **Click [Setting].**

The shortcut key set in step 2 - 3 appears in the blank space.
If click [Clear], the shortcut settings are canceled.

[Use “Pause” key to stop/continue Live Mode]: Check this to run/stop live-mode/multi live-mode by pressing the Pause key.

Note

In live mode and multi live mode, the shortcut key switches the mode without stopping live mode.

Other1

Perform other settings.



■Setting Favorites

It is possible to assign a different name to connected projectors.
The name appears at the bottom of the <Projector Search> window.
Click [Settings] to display the <Register Favorite Name> screen, and enter a name for the projector.



■Automatic connection setting

You can perform automatic settings for newly connected projectors.

- If the [Make an automatic connection] box is checked and a projector is registered as a destination for automatic connection when Wireless Manager ME 5.5 is started, <Projector Search> window – [S-MAP] do not appear and connection is performed automatically.
- When [Setting] is clicked, <Access Log> window appears and you can select projector(s) for automatic connections. Up to 10 projectors may be displayed in the order of most recent connection history. When it is desired to remove a projector from the display list, select it and press the [DELETE] → [OK] button.



Setting options (cont.)

■User settings

• User name
When [Setting] is clicked, the <User name setting> window to the right appears.
Specify the icon and user name shown on the <Projector Search> window ([S-MAP], [1-4/U]).

Note

Enter the user name in up to 8 alphanumerics.

• Favorites Button
Assign whichever function you like to a specific launcher button. (See page 33)

: [Select Access Port]
: [Option]
: [Selective Area Transmission]
: [Virtual Remocon]
: [WEB control]
: [AV Mute]
: [Display Change]
: [None]

Other2

Perform other settings.



■Network

Set the wired LAN and wireless LAN adapter used to connect to the projector.
[Wired LAN Adapter]:
Adapter used when connecting to the projector via a wired LAN.
[Wireless LAN Adapter]:
Adapter used when connecting to the projector via a wireless LAN.

※ The displayed (selected) LAN adapter is used to connect to the projector.

■Firewall/Wireless LAN Utility Message

• [Firewall confirmation message will be displayed when switching on.]
The firewall confirmation message for the firewall that is operating when the application starts is displayed.
• [Wireless LAN adapter utility confirmation will be displayed when making connection.]
When switching network connections, if the wireless LAN adapter utility is operating, a confirmation message is displayed.

※ If the box for the confirmation is unchecked, the message will no longer be displayed.

Version information

The version information of Wireless Manager ME 5.5 is displayed when [i] on the <Option> window is clicked.

Network/Security setting of the projector

When making a connection between a computer and a projector with settings other than the default settings, perform the procedure below to display the menu required when changing the initial settings. For detailed setting, see the operation manual for your projector.

Displaying the Network Menu

1 Press the [MENU] button on the projector.

The main menu appears.



2 Select [NETWORK] with the [▲▼] buttons.

The network menu appears.



Notes

- The screen shown above is an example of PT-FW300NTE/F300NTE.
- Depending on the signals which are input to the projector, it may not be possible to adjust some of the items and use some of the functions. In the case of an item that cannot be adjusted or a function that cannot be used, the corresponding on-screen item will not be displayed, and you will not be able to execute it even when you press the [ENTER] button.
- The displayed screen, name and operation vary depending on the type of projectors. For details, see the operation manual for your projector.

Network/Security setting of the projector (cont.)

Wired LAN settings

You can make detailed wired LAN settings.

Select [WIRED LAN] at the network menu and click the [ENTER] button.



DHCP※:

ON: If a DHCP server exists in the network to which the projector is connected, the IP address will automatically be acquired.

OFF: If a DHCP server does not exist in the network to which the projector is connected, additionally set [IP ADDRESS※], [SUBNETMASK※] and [DEFAULT GATEWAY※].

※ “Glossary” (See page 70)

Note

A wired LAN and wireless LAN cannot be used in the same segment.

Default wired LAN settings

The following wired LAN settings are set before the projector leaves the factory.

DHCP	: OFF
IP ADDRESS	: 192.168.10.100
SUBNETMASK	: 255.255.255.0
DEFAULT GATEWAY	: 192.168.10.1

Network/Security setting of the projector (cont.)

Setting network number (for wireless LAN)

1 **Select [WIRELESS LAN] at the network menu.**

2 **Select the number to be connected with the [◀ ▶] buttons.**



• Network number
Off, [S-MAP], [1]-[4], [USER1]-[USER3]

Note

Selecting [OFF] disables the wireless LAN.

[USER] settings

You can configure more precise network settings, if you select from [USER1] to [USER3] (user) for [Wireless LAN] in the network menu. For network settings, contact your network administrator.

Setting IP

■How to display IP address setting menu

Press [WIRELESS LAN]→[USER1] - [USER3]→[ENTER] at the network menu.



DHCP※:
ON: If a DHCP server exists in the network to which the projector is connected, the IP address will automatically be acquired.
OFF: If a DHCP server does not exist in the network to which the projector is connected, additionally set [IP ADDRESS※], [SUBNETMASK※] and [DEFAULT GATEWAY※].

※ “Glossary” (See page 70)

Note

A wired LAN and wireless LAN cannot be used in the same segment.

Network/Security setting of the projector (cont.)

Wireless settings

Select [NEXT] on the IP address setting window to switch to the wireless setting window.
Make the settings related to the wireless connection between the projector and the network.



■ SSID※ : If the mode is [INFRASTRUCTURE※], enter the SSID registered at the access point. If the mode is [AD HOC], enter the same character string as that of SSID set on the computer to be connected.

Note

SSID has to be entered in lower-case alphanumeric letters.

■ MODE : Select [AD HOC] or [INFRASTRUCTURE].
AD HOC※ : Connect projector and computer directly without access point.
INFRASTRUCTURE※ : Connect through access point.

■ AUTHENTICATION : Set the user authentication method used by the network to be connected.
OPEN : Select when making a connection using [AD HOC], or when the access point authentication method is OpenSystem※.
SHARED : Select when making a connection using [AD HOC], or when the access point authentication method is Shared Key※.
WPA-PSK※ : Select when the access point authentication method is WPA-PSK.
WPA2-PSK※ : Select when the access point authentication method is WPA2-PSK.

■ ENCRYPTION : Select the encryption method to be used for communication between the projector and the network.
NONE : Select when transmit without encryption. It is selectable only when [AUTHENTICATION] is [OPEN] or [SHARED].
WEP※ : Select when ENCRYPTION is WEP.
TKIP※ : Select when ENCRYPTION is TKIP.
Selectable when [AUTHENTICATION] is either [WPA-PSK] or [WPA2-PSK].
AES※ : Select when ENCRYPTION is AES.
Selectable when [AUTHENTICATION] is either [WPA-PSK] or [WPA2-PSK].

※ “Glossary” (See page 71)

Notes

- If you are unable to connect to the wireless LAN through the access point even after performing the steps in “① Projector settings (See page 24),” contact the manufacturer of the access point.
- IEEE802.1x is not supported.
- If you finished entering settings, press [NEXT].

Network/Security setting of the projector (cont.)

Additionally perform the following setting using the [AUTHENTICATION] setting.



■ When setting [OPEN] or [SHARED] as authentication and setting [WEP※] as the encryption method:
DEFAULT KEY : Set 1 – 4 numerals for the default key.
KEY 1 – 4 : Set these to match the WEP key registered in [DEFAULT KEY] and select [OK].
Either the 64-bit or 128-bit WEP key can be set. For the 64-bit key, input five alphanumerics (or a 10-digit string for the hexadecimal format) for the 128-bit key, input 13 alphanumerics (or a 26-digit string for the hexadecimal format).

■ When using [WPA-PSK※] or [WPA2-PSK※] : Set key and select [OK].
Input either 8 to 63 alphanumerics or a 64 digit string in the hexadecimal format.

Note

Important video/audio data is protected because AES※ encryption processing takes place in advance for all network numbers, even if [ENCRYPTION] is set to [NONE].

※ “Glossary” (See page 71)

Default settings of [USER1] - [USER3]

The following settings as [USER1] - [USER3] in the wireless LAN are set before the projector leaves the factory.

SSID	: Panasonic Projector
DHCP	: OFF
IP ADDRESS	: 192.168.11.100
SUBNETMASK	: 255.255.255.0
DEFAULT GATEWAY	: 192.168.11.1
MODE	: AD HOC
AUTHENTICATION	: OPEN
ENCRYPTION	: NONE
CHANNEL	: 11

Network/Security setting of the projector (cont.)

Changing the projector name

You can change the projector name on the network.
It will help to distinguish names in the <Projector Search> window ([S-MAP], [1-4/U]).

1 Select [NAME CHANGE] at the network menu and press the [ENTER] button.



2 Enter the projector name using the [◄►▲▼ENTER] buttons.

Select [ALL DELETE] to remove all the entered characters. Press the [DEFAULT] button on the remote-controller to clear a letter which is selected by the cursor in the entry box.

3 After entering the projector name, select [OK] and click [ENTER].

Select [CANCEL] to undo the changes and then press [ENTER].



Password setting

This setting is used to limit the users that can connect to the projector.

1 Select [PASSWORD] at the network menu.



2 Select [ON] with the [◄ ►] buttons.

3 Select [PASSWORD CHANGE] at the network menu and press the [ENTER] button.



4 **Enter the password using the [◄►▲▼ENTER] buttons.**

Select [ALL DELETE] to remove all the entered characters. Press the [DEFAULT] button on the remote control to clear a letter which is selected by the cursor in the entry box.

5 **After entering the password, select [OK] and click [ENTER].**

Select [CANCEL] to undo the changes and then press [ENTER].

Note

It is recommended to change password on a regular basis for keeping it private.



Network standby

Set it to “ON”, if you want to turn on the projector in standby mode from the PC that is connected to the network via wired LAN or wireless LAN.

1 **Select [NETWORK STANDBY] at the network menu.**



2 **Select [ON] or [OFF] with the [◄ ►] buttons.**

Note

This is an example of when the displayed screen is the PT-FW300NT/F300NT screen. The standby setting procedure differs depending on the model.

Example:• [NETWORK] → [NETWORK STANDBY]

• [PROJECTOR SETUP] → [STANDBY MODE]

For details, see the operation manual for your projector.

Network control

Set it to “ON”, if you want to control the projector from the PC that is network-connected.

1 **Select [NETWORK CONTROL] at the network menu.**



2 **Select [ON] or [OFF] with the [◄ ►] buttons.**

Note

If you turn on [NETWORK CONTROL], “WEB control”, “PJLink™” and “Command control” are available.

Network/Security setting of the projector (cont.)

Live mode cut-in

Set it to “ON” if you allow other users on the network to connect in live mode while you are also in live mode.

1 **Select [LIVE MODE CUT IN] at the network menu.**



2 **Select [ON] or [OFF] with the [◀ ▶] buttons.**

Computer search

You can perform the same operation in stead of using the [COMPUTER SEARCH] button on the remote control.

1 **Select [COMPUTER SEARCH] from the network menu, and then press [ENTER].**



Multi-live

You can perform the same operation in stead of using the [MULTI-LIVE] button on the remote control.

1 **Select [MULTI-LIVE] from the network menu, and then press [ENTER].**



Network/Security setting of the projector (cont.)

Verifying settings

Your current settings appear.

Select [STATUS] at the network menu and press the [ENTER] button.



The status of the following will appear.

WIRED LAN

DHCP	“ON” - “OFF”
IP ADDRESS	(See page 52)
SUBNETMASK	(See page 52)
DEFAULT GATEWAY	(See page 52)
MAC ADDRESS	

WIRELESS LAN

ANTENNA LEVEL	(The strength of the connection will appear.)
NETWORK	“S-MAP”, “1” - “4”, “USER1” - “USER3”
MODE	“AD-HOC” - “INFRASTRUCTURE”
CHANNEL	Refer to page 5 for usable channels.
SSID	(See page 54)
AUTHENTICATION	“OPEN” - “SHARED”-“WPA-PSK”-“WPA2-PSK”
DEFAULT KEY	“-” - “1” - “4”
ENCRYPTION	“NONE” - “WEP” - “TKIP” - “AES”
DHCP	“ON” - “OFF”
IP ADDRESS	(See pages 53, 55)
SUBNETMASK	(See pages 53, 55)
DEFAULT GATEWAY	(See pages 53, 55)
MAC ADDRESS	

Returning to the initial settings

You can reset the network setting to the factory default of the projector.

1 **Select [INITIALIZE] at the network menu and press the [ENTER] button.**



Note

The entry of the password is prompted if [Password setting] is turned [ON] in the “ Security” menu.

2 **Select [OK] with the [◄ ►] buttons and press the [ENTER] button.**



Using WebBrowser

Control a projector through the WebBrowser of a computer. It is called “WEB Control”.
(The example is when using Microsoft Internet Explorer.)

Note

The functions that can be operated and content displayed differ depending on the projector you are using.

Before using the WebBrowser control

Connect the projector and PC with wired or wireless LAN. (See page 15)

① Projector settings

Turn [ON] the [NETWORK CONTROL] in the network menu.

1 **Select [NETWORK CONTROL] in the network menu.**

2 **Select [ON] or [OFF] with the [◀ ▶] buttons.**

ON : This enables control on the WebBrowser.
OFF : This disables control on the WebBrowser.



Notes

- When the projector settings have been changed using a WebBrowser, the projector will not appear on the connection list until the projector network is switched to [USER 1] - [USER 3].
- After the projector network has been switched to [USER 1] - [USER 3], manually release the proxy settings of the WebBrowser used.

② Computer settings

■Proxy server settings

Release the proxy settings of the WebBrowser used.

1 **Open <Internet Properties> window.**

Click [Start] → [Control Panel] → [Network and Internet Connections] → [Internet Option].

2 **Open [Connections] → [LAN Settings].**

3 **If [Use a proxy server for your LAN] is checked, remove the check.**

If [Use automatic configuration script] has been checked, remove the check.


Local Area Network (LAN) Settings
Automatic configuration
Automatic configuration may override manual settings. To ensure the use of manual settings, disable automatic configuration.
Automatically detect settings
Use automatic configuration script
Address
Proxy server
Use a proxy server for your LAN (These settings will not apply to dial-up or VPN connections).
Address: 132.182.56.3
Port: 8080
Advanced...
Bypass proxy server for local addresses
OK
Cancel

4 **Click [OK].**

■Enabling JavaScript

If JavaScript has been set to disable, enable it.

1 **Open <Internet Properties> window.**

Click [Start] → [Control Panel] → [Network and Internet Connections] → [Internet Option].

2 **Select [Security] and set the security level to [Default Level], or select [Custom Level] and check the [Enable] checkbox under [Active scripting].**

Accessing from the WebBrowser

1 **Click [WEB CONTROL] on the launcher.**
Or start up the WebBrowser, and enter the IP address set by the projector.

The WebBrowser starts up and the authentication window appears.

<Top window>



2 **Enter the user name and the password.**

3 **Click [OK].**

<Monitored information> window appears. (Next page)

Notes

- The default user mane and password settings are as follows:
  User name: user1 (with user authority) / admin1 (administrator authority)
  Password: panasonic (lower case)
  Depending on the model, no password is set.
- Administrator authority has full access to the all features. User authority has access to “monitor information”, “projector control” and “password change”. (User authority has no access to “Detailed setting”.)
- Password used in this page is for accessing the web control window. (See page 67)
  This password is different from the password set in page 56 for accessing a projector.
- The system locks for several minutes if an incorrect password is entered three times in succession.
- If you reset the configuration to the factory default or the state of purchase, the password is reset to “panasonic”. Change the password to an appropriate one.
- Make sure the password is as hard to guess as possible.
- Change the password periodically.
- If you have forgotten the password, perform [INITIALIZE] in the projector's network menu (See page 59), and set a new one in the “Password change” window of your WebBrowser. (See page 67)
- Panasonic Corporation and its affiliated companies never directly ask customers for their password.
  Do not give out your password even if directly asked by a third-party representing themselves as Panasonic Corporation.
- The top window may not appear depending on the WebBrowser. In this case start up WebBrowser again, or press the [Ctrl] + [R] keys for example to update the screen.
- Connection cannot be made while the WebBrowser is set to dial-up network. Cancel the dial-up network setting.
- It may take some moments for WebBrowser to start up.

Using WebBrowser (cont.)

Monitor information window

This page indicates the projector status.
To access this page from other pages, click [Status] at the left of the window.

■Projector status

On this window, click the [Projector status] tab.



■Network status

On this window, click the [Network status] tab.



Note

The monitor information is refreshed at fixed intervals, but the current exact information can be checked by clicking [View] → [Refresh].

If [SELF TEST Error (Detail)] appears on the monitored information window, click it to view the error details.



■ If [FAILED] appears

Item	Description
MAIN CPU BUS	There is a problem with a microcontroller circuit. Contact your dealer.
FAN	There is a problem with the fan or fan drive circuit. Contact your dealer.
INPUT AIR TEMPERATURE	Input air temperature is high. The projector is likely being used in a high temperature environment such as near heating equipment.
OUTPUT AIR TEMPERATURE	Temperature surrounding the lamp is high. The exhaust vent is likely blocked.
LAMP REMAIN TIME	The lamp has been used for longer than its rated useful life, and it is time to replace it.
LAMP STATUS	The lamp could not be lit. Allow the bulb of the light source to cool, and then turn on the projector.
INPUT AIR TEMP.SENSOR	There is a problem with the air intake temperature sensor. Contact your dealer.
OUTPUT AIR TEMP.SENSOR	There is a problem with the exhaust temperature sensor. Contact your dealer.
BATTERY	The battery must be replaced. Contact your dealer.
ACF UNIT	Either the ACF unit is not set properly or it does not work. For further detail, see the instruction manual for the projector.
FILTER REMAIN	The remaining filter gets low. For further detail, see the instruction manual for the projector.

Using WebBrowser (cont.)

Projector control window

You can make various projector settings.
If you migrate from other page, click [Projector control] in the main menu (left of the window).

■Basic control window

On this window, click the [Basic control] tab.



■Advanced control window

On this window, click the [Advanced control] tab.



Note

Connection with the projector may not be possible immediately after the power is turned on. In this case wait a bit and then make the connection again.

Detailed settings window

You can make detail network settings on projector, when connecting without the administrator authority or when connecting through an access point (infrastructure mode).

■LAN settings

1 **Click [Detailed set up] in the menu.**



2 **Select the items to change and click [Next].**

The settings window appears, showing the current settings.
- To change the LAN settings, click [Change].
- To return to the previous window, click [Back].

Settings in this page are the same when setting [USER 1] - [USER 3] from network menu of the projector. (See page 53)

3 **Complete the detailed settings and click [Next].**

When [Next] is clicked, the next page appears, enabling you to complete the detailed settings as desired.
After all required items have been entered, a confirmation window appears.



4 **Click [Submit].**

The settings will be registered.



■Making the above settings effective

Select [WIRELESS LAN] in the network menu of the projector, and use the [◀ ▶] buttons to select the network set in this page.

Notes

- Important video/audio data is protected because AES※ encryption processing takes place in advance for all network numbers, even if [ENCRYPTION] is set to [NONE]. ※ “Glossary” (See page 71)
- If you have changed the LAN settings that are currently in use, the connection may break off.

Using WebBrowser (cont.)

■Time settings



Click [Detailed set up]→[Adjust clock] in the menu.

Time zone : Select the time zone and click [Set time zone].

Time : Enter the current date and time in [Date] and [Time], and then click [Set date and time].

■Email settings



You can specify two email recipients.
Click [Detailed set up]→[E-mail set up] in the menu.

• [MAIL SERVER]
ENABLE : Enable or disable email transmission.
SMTP SERVER NAME : Enter the SMTP server name.

• [MAIL OPTION]
MAIL FROM : Enter the sender's email address.
MEMO : Enter a description of the sender.

• [TEMPERATURE WARNING SET UP]
MINIMUM TIME : Enter the interval for sending email.
INPUT AIR TEMPERATURE: Select the temperature of the intake sensor at which to send a warning message.

• [E-MAIL ADDRESS]
E-MAIL ADDRESS : Enter the email addresses of the recipients.
MAIL CONTENTS : Change the type of message as desired. When sending messages to mobile phones, select "SIMPLE."
ERROR : Select ON to send email when errors occur.
LAMP RUNTIME : Select ON to send email when "at REMAIN" is reached.
FILTER REMAINING TIME : Select ON to send email when "at REMAIN" is reached.
INPUT AIR TEMPERATURE: Select ON to send email when the temperature set in [TEMPERATURE WARNING SET UP] is exceeded.
PERIODIC REPORT : Send a message with the projector status at the selected date and time.

When [submit] is clicked, the settings are applied.

■Connection test



You can confirm if a network connection is established with Mail server, POP server, DNS server or the like.
Click [Detailed setup] → [Ping test] from the network main menu.

Destination IP address: Enter the IP address of the server you want to test, and then click [Submit].

If succeeded in connection, the following display appears.

```
PING 198.245.80.10 (198.245.80.10): 56 data bytes
64 bytes from 198.245.80.10: icmp_seq=0 ttl=255 time=0.7 ms
64 bytes from 198.245.80.10: icmp_seq=1 ttl=255 time=0.4 ms
64 bytes from 198.245.80.10: icmp_seq=2 ttl=255 time=0.4 ms
64 bytes from 198.245.80.10: icmp_seq=3 ttl=255 time=0.4 ms

--- 198.245.80.10 ping statistics ---
4 packets transmitted, 4 packets received, 0% packet loss
round-trip min/avg/max = 0.4/0.4/0.7 ms
```

If failed in connection, the following display appears.

```
PING 198.245.80.100 (198.245.80.100): 56 data bytes

--- 198.245.80.100 ping statistics ---
4 packets transmitted, 0 packets received, 100% packet loss
```

Using WebBrowser (cont.)

※Example of email message sent

■If [NORMAL] is selected under [MAIL CONTENTS]

① If you have completed the email settings

```
=== Panasonic projector report(CONFIGURE) ===
Projector Type    : F300NT

-----  E-mail setup data -----
TEMPERATURE WARNING SETUP
MINIMUM TIME      at [ 60] minutes interval
INPUT AIR TEMPERATURE  Over [ 32C / 89F ]

ERROR                  [ ON  ]
LAMP RUNTIME           [ ON  ]   at REMAIN [ 400] H
LAMP RUNTIME           [ ON  ]   at REMAIN [ 200] H
FILTER REMAIN          [ ON  ]   at REMAIN [ 500] H
FILTER REMAIN          [ ON  ]   at REMAIN [   0] H
INPUT AIR TEMPERATURE  [ ON  ]
PERIODIC REPORT
Sunday    [ ON  ]  Monday   [ ON  ]  Tuesday   [ ON  ]  Wednesday [ ON  ]
Thursday  [ ON  ]  Friday   [ ON  ]  Saturday  [ ON  ]

00:00  [ ON  ]    01:00  [ ON  ]    02:00  [ ON  ]    03:00  [ ON  ]
04:00  [ ON  ]    05:00  [ ON  ]    06:00  [ ON  ]    07:00  [ ON  ]
08:00  [ ON  ]    09:00  [ ON  ]    10:00  [ ON  ]    11:00  [ ON  ]
12:00  [ ON  ]    13:00  [ ON  ]    14:00  [ ON  ]    15:00  [ ON  ]
16:00  [ ON  ]    17:00  [ ON  ]    18:00  [ ON  ]    19:00  [ ON  ]
20:00  [ ON  ]    21:00  [ ON  ]    22:00  [ ON  ]    23:00  [ ON  ]

-----  check system -----
MAIN CPU BUS           [    OK    ]
FAN                    [    OK    ]
INPUT AIR TEMPERATURE  [    OK    ]
OUTPUT AIR TEMPERATURE [    OK    ]
LAMP REMAIN TIME       [    OK    ]
LAMP STATUS            [    OK    ]
INPUT AIR TEMP.SENSOR  [    OK    ]
OUTPUT AIR TEMP.SENSOR [    OK    ]
BATTERY                [    OK    ]
ACF UNIT               [    OK    ]
FILTER REMAIN     [    OK    ]
(Error code 00 00 00 00 00 00 00 00)

Input air temperature      :-44 degC / -47 degF
Output air temperature     : 30 degC /  86 degF
SET RUNTIME       188 H
POWER ON            0 times
LAMP  ON           21 times
LAMP  HIGH         30 H
LAMP  REMAIN     4970 H
FILTER REMAIN       0 H

-------- Current status ---------
MAIN VERSION        1.00.0
NETWORK VERSION     1.00
LAMP STATUS         LAMP=OFF
INPUT SIGNAL        NETWORK   ---
                    ---kHz / ---Hz
REMOTE2 STATUS      DISABLE

----- Wired Network configuration -----
DHCP Client  OFF
IP address   10.69.104.183
MAC address  00:40:63:00:00:12

----- Wireless Network configuration -----
IP address   169.254.213.197
MAC address  00:0E:10:02:6E:7E

Wed Sep 17 13:45:42 2008

----- Memo -----
```

② If an error occurs

```
=== Panasonic projector report(ERROR) ===
Projector Type          : FW300NTU

-----  check system -----
MAIN CPU BUS                [ FAILED ]
FAN                         [   OK   ]
INPUT AIR TEMPERATURE       [   OK   ]
OUTPUT AIR TEMPERATURE      [   OK   ]
LAMP REMAIN TIME            [   OK   ]
LAMP STATUS                 [ FAILED ]
INPUT AIR TEMP.SENSOR       [ FAILED ]
OUTPUT AIR TEMP.SENSOR      [   OK   ]
BATTERY                     [   OK   ]
ACF UNIT                    [ FAILED ]
FILTER REMAIN               [   OK   ]
(Error code 84 44 00 00 10 00 00 04)

Input air temperature      :-44 degC / -47 degF
Output air temperature     : 29 degC /  84 degF
SET RUNTIME       194 H
LAMP  ON           21 times
LAMP  HIGH         36 H
LAMP  REMAIN     4964 H

-------- Remaining filter ---------
QUANTITY            0 %
APPOROX. TIME       0 H

-------- Current status ----------
MAIN VERSION        1.00.0
NETWORK VERSION     1.000
LAMP STATUS         LAMP=OFF
INPUT SIGNAL        NETWORK   ---
                    ---kHz / ---Hz
REMOTE2 STATUS      DISABLE

----- Wired Network configuration -----
DHCP Client  OFF
IP address   10.69.104.183
MAC address  00:40:63:00:00:12

----- Wireless Network configuration -----
IP address   169.254.213.197
MAC address  00:0E:10:02:6E:7E

Wed Sep 17 13:45:42 2008

----- Memo -----
```

■If [SIMPLE] is selected under [MAIL CONTENTS]

③ If you have completed the email settings

```
Projector Type:
[F300NT]

--- E-mail setup data
-TEMP. WARNING SETUP
MINIMUM TIME :
 at [ 30] minutes interval
INPUT AIR TEMP. :
 Over [ 32C / 89F ]
-
ERROR         [ON ]
LAMP REMAIN [1000H]
LAMP REMAIN [ 999H]
INPUT TEMP.  [ON ]
-PERIODIC REPORT
Sun[ON ] Mon[ON ]
Tue[ON ] Wed[ON ]
Thu[ON ] Fri[ON ]
Sat[ON ]
00:00[ON ] 01:00[ON ]
02:00[ON ] 03:00[ON ]
04:00[ON ] 05:00[ON ]
06:00[ON ] 07:00[ON ]
08:00[ON ] 09:00[ON ]
10:00[ON ] 11:00[ON ]
12:00[ON ] 13:00[ON ]
14:00[ON ] 15:00[ON ]
16:00[ON ] 17:00[ON ]
18:00[ON ] 19:00[ON ]
20:00[ON ] 21:00[ON ]
22:00[ON ] 23:00[ON ]

--- check system
FAN    [   OK   ]
LAMP   [   OK   ]
TEMP.  [   OK   ]
FILTER [   OK   ]
OTHER  [   OK   ]
Error code :
 00 00 00 00
 00 00 00 00
--- Tempurature
Input air:
  27 C /  80 F
Output air:
  30 C /  86 F

--- Lamp remain
LAMP     1000 H


----- Memo -----
```

④ If an error occurs

```
Projector Type:
[F300NT]

--- check system
FAN    [ FAILED ]
LAMP   [   OK   ]
TEMP.  [   OK   ]
FILTER [   OK   ]
OTHER  [   OK   ]
Error code :
 40 00 00 00
 00 00 01 00
--- Tempurature
Input air:
  27 C /  80 F
Output air:
  26 C /  78 F

--- Lamp remain
LAMP      999 H


----- Memo -----
```

Using WebBrowser (cont.)

■Authentication server settings



Click [Detailed set up]→[Authentication set up] in the menu.

Auth : Change the authentication method as desired.

SMTP Auth : For SMTP authentication, change the authentication method to use, as desired.

Pop Server name : Enter the POP server name.

User name : Enter the user name for the SMTP or POP server.

Password : Enter the password for the SMTP or POP server.

SMTP server port : Enter the SMTP server port number.

POP server port : Enter the POP server port number.

■Command port settings



In the main menu, click [Detailed set up] and [Command port setting].

Command port : Specify a port number to be used for command control.

■Password settings



Click [Change password] in the main menu.

Set a password for access of the [Projector control window].
Enter the previous password and the new password.
Enter the new password in [Retype] and click [OK].

Notes

- You can enter a password up to 16 characters (upper case/lower case) and symbols.
- You can reset the password of users with user authority, when you logged in as administrator.

Switching Languages

Switch the language of the WEB control window.
To access this page from other pages, click [English] [日本語] at the main menu.

Using PJLink™ protocol

The projector's network functions conform to PJLink™ Class 1 standards, enabling the following operations from a computer using the PJLink™ protocol.
• Setting the projector
• Querying the projector status

Note

To use PJLink™ protocol, select [ON] to turn on the [NETWORK CONTROL] of the projector. (See page 57)

Applicable commands

The following commands are used to control the projector with the PJLink™ protocol.

Command	Control details	Notes
POWR	Power control	Parameters 0 = Standby 1 = On
POWR ?	Power status query	Parameters 0 = Standby 1 = On 2 = Cooling down 3 = Warming up
INPT	Input switching	Parameters 11 = COMPUTER1 12=COMPUTER2 21 = VIDEO 22=S-VIDEO 31 = DVI 51 = NETWORK
INPT ?	Input switching query	
AVMT	AV mute control	Parameters 30 = AV mute off (video mute cancelled) 31 = AV mute on (video mute)
AVMT ?	AV mute status query	
ERST?	Error status query	Parameters 1st byte : Indicates fan errors; a number from 0 to 2 2nd byte : Indicates lamp errors; a number from 0 to 2 3rd byte : Indicates temperature errors; a number from 0 to 2 4th byte : Fixed at 0 5th byte : Indicates filter errors; a number from 0 to 2 6th byte : Indicates other errors; a number from 0 to 2 Numbers from 0 to 2 indicate the following 0 = No error detected 1 = Warning 2 = Error
LAMP ?	Lamp status query	Parameters 1st number (1–5 digits): Cumulative hours of lamp use 2nd number: 0 = lamp off; 1 = lamp lit
INST ?	Input switching list query	The following values are returned in this parameter "11 12 21 22 23 51"
NAME ?	Projector name query	Returns the name set in "HOSTNAME※," in "NETWORK" ※The "HOSTNAME" is the projector name set in the projector itself.
INF1 ?	Manufacturer name query	Returns "Panasonic"
INF2 ?	Model name query	Returns "F300NT" / "FW300NT" (Answer the name of the projector in use.)
INFO ?	Query for other information	Returns the version number or similar identification
CLSS ?	Class information query	Returns "1"

■PJLink™ security authentication

The password used for PJLink™ is same as the one you set in the Web control.
Configure this without specifying the password for the Web control, if you use it without authentication.
PJLink™ is a pending trademark in Japan, the United States and other countries and regions. For details on PJLink™ specifications, refer to the Japan Business Machine and Information System Industries Association website.
The URL is http://pjlink.jbmia.or.jp/english/

Software Uninstall

Wireless Manager ME 5.5

From the desktop, select [Start] → [All Programs] → [Panasonic Wireless Display] → [Uninstall Wireless Manager mobile edition 5.5].

Follow the instructions appearing on the screen and uninstall the software.

Glossary

Category	Item	Descriptions	Page
Common Setting of connections	**LAN**	Abbreviation for Local Area Network. This is a network with a relatively narrow range such as inside a company.	**10**
	Access point	These are stations for relaying electromagnetic signals between computers in a wireless LAN. When a computer is connected to an access point, it can communicate through the network connected to the access point.	**24**
	MAC address	Each network card has its own ID No. A discrete ID No. is assigned to each and every network card around the world. These IDs are used to exchange data between cards. These IDs are a combination of a discrete number managed and assigned by the IEEE to each individual manufacturer and a unique number assigned to each individual card by the manufacturer.	**24**
	IP address	Internet Protocol (IP) is a protocol for distributing data, and the address corresponding to the data distribution destination is called the IP address. The same IP address cannot be used within the same LAN.	**25** **29** **52** **53**
	DHCP	Abbreviation for Dynamic Host Configuration Protocol. This function automatically assigns IP addresses to the connected equipment. If a device with the DHCP server function is present within a LAN, it automatically assigns IP addresses to the connected equipment.	**25** **52** **53**
	Subnetmask	This limits the range of the IP addresses assigned to computers in order to divide the network into a number of sections during TCP/IP connection. The value used to divide the network at this time is called the subnetmask.	**25** **52** **53**
	Default Gateway	The devices that are used for different network standards from yours. Default Gateway enables a connection with other network, by adjusting bilateral differences such as communication protocols. If no gateway is specified for the IP address of access destination, data will be sent to the host set as the default gateway.	**52** **53**
	Domain Name	The identifier that corresponds to the location to which data is delivered by the network. It is an alias name consisting of alphabet, numbers, and symbols that replace the more difficult to use enumerated IP address.	**29**

Glossary (cont.)

Category	Item	Descriptions	Page
Advanced setting of connection	**AD_HOC**	This is the mode in which computers communicate with each other directly, rather than via access points.	**25 54**
	INFRASTRUCTURE (infrastructure mode)	This is the mode in which communications are performed via the access point.	**24 54**
	SSID	Abbreviation for Service Set ID. The SSID identification code must be set to distinguish equipment included in a wireless LAN that uses access points from equipment not included in that LAN. This may appear as the “ESSID” or the “network name” for wireless LAN adapters made by some manufacturers.	**25 54**
	Open System/ OPEN	This is an authentication of wireless signals employing a public key encryptosystem.	**25 54**
	Shared Key/ SHARED	This is a secret key encryptosystem for wireless signals in which authentication is performed with a key pre-set in the WEP. Other terms for this method, in which the same key is used for both encryption and decryption, are “shared key encryptosystem” and “common key encryptosystem”.	**25 54**
	WPA-PSK WPA2-PSK	This is a standard covering encryption methods used in wireless LAN. It provides greater security than WEP, and has functions such as a user authentication function and also TKIP (encryption protocol) which automatically changes the encryption key at fixed intervals. And this authentication requires no authentication server.	**54 55**
	WEP	Abbreviation for Wired Equivalent Privacy. This is a method for encrypting communication data. The encryption key is created and notified only to the communicating user, so the communication data cannot be decrypted by a third party.	**17 25 54 55**
	TKIP	Abbreviation for Temporal Key Integrity Protocol. This encryption protocol provides even greater security than WEP because it changes the encryption key at fixed intervals.	**54**
	AES	Next generation standard cryptography standerdized by the National Institute of Standards and Technology (NIST). AES: Advanced Encryption Standard	**17 54 55 64**

Frequently Asked Questions

Check the following points once more before requesting repair.

No wireless connection can be made between my projector and my computer.

• **Is Wireless Manager ME 5.5 running?**
Wireless Manager ME 5.5 must be started in the computer in order to enable wireless transmissions of images to the projector.

<When a setting error for the wireless LAN adapter has been detected>

① **Is the wireless LAN adapter effective?**
If the wireless LAN adapter is disabled, enable it.
For some PCs with an internal wireless LAN, the hardware switch or the software setting might have turned off the wireless LAN.
If it is turned “OFF,” turn it “ON” before start Wireless Manager ME 5.5.
(For some Bluetooth-equipped PCs, Bluetooth might be set at higher priority; switch the priority to wireless LAN.)
Refer to the operation manual of your PC for information about switching on/off.

② **Is your wireless LAN adapter properly recognized on the network?**
Sometimes, cards are not correctly recognized by the computer. Check Windows [Device Manager] to make sure your card has been recognized.
If the Network Adapter is indicated with [?] in [Device Manager], wireless LAN adapter installation is not complete. See the User’s Manual of your card and re-install the card driver.

■ **To display [Device Manager]**

• **In Windows XP**
Click [Start] → [Control Panel] → [Performance and Maintenance] → [System]. This will bring up the [System Properties] dialog box. Click [Device Manager] in the [Hardware] tab.

• **In Windows Vista**
Click [Start] → [System and Maintenance] → [System]. This will bring up [View basic information about your computer]. Click [Device Manager].

• **In Windows 7**
Click [Start] → [System and Security] → [System] to display [View basic information about your computer]. Click [Device Manager].

③ **Some wireless LAN adapters may allow Easy Wireless Set Up connections to function if drivers are updated.**
(Consult the manufacturer of your driver about updates.)

Frequently Asked Questions (cont.)

No wireless connection can be made between my projector and my computer. (cont.)

<When the Network Bridge setting has been detected>

Is Network Bridge enabled?

If you are using Windows XP, Windows Vista, or Windows 7, Network Bridge may be set. (Network Bridge is a function of Windows XP, Windows Vista, and Windows 7.)

The settings in Network Bridge must be changed in order to make a wireless connection. If you do not expect ever to use Network Bridge and see no need for it, delete it from your system.

■ **To verify whether your system has Network Bridge (Windows XP)**

Choose [Connect to] on the [Start] menu and click [Show all connections]. Verify that [Network Bridge] is displayed in the <Network Connections> window. Perform either ① or ② below.

① **How to change settings in Network Bridge**

1. Select [Connect to] on the [Start] menu and click [Show all connections].
2. Right-click [Network Bridge] and click [Properties].
3. Remove the check mark from the [Wireless Network Connection] box in the [Network Bridge Properties] dialog box (if the box is not checked, proceed to step 4.)
4. Click [Properties] in [Internet Protocol (TCP/IP)] in the [Network Bridge Properties] dialog box.
5. Click the [Alternate Configuration] tab in the [Internet protocol (TCP/IP) properties] dialog box.
6. Check the [User configured] box and set the [IP address] and [subnetmask] as follows:
   IP address : 10. 10. 11. 101
   [subnetmask] : 255.255. 0. 0
   (If the above IP address is already in use in the LAN environment, change it as appropriate in Class A. Confirm to your system administrator on network settings before changing any settings.)
7. Click [OK] → [Close].
8. Close the [Network Connections] dialog box.

② **How to delete the network bridge**

1. Select [Connect to] on the [Start] menu and click [Show all connections].
2. Right-click [Network Bridge] and click [Delete].

■ **To verify whether your system has a Network Bridge (Windows Vista)**

Select [Control Panel] on the [Start] menu, and double-click on [Network and Sharing Center]. Select [Manage network connections] in the [Network and Sharing Center] dialog box. Verify that [Network Bridge] is displayed in the [Network connection] dialog box.

Perform either ① or ② below.

① **How to change settings in Network Bridge**

1. Select [control panel] on the [Start] menu, and double-click on [Network and Sharing Center].
2. Select [Manage network connections] in the [Network and Sharing Center] dialog box.
3. Right-click [Network Bridge] and click [Properties].
4. Click [Continue] in [User Account Control].
5. Remove the check mark from [Wireless Network Connection] box in the [Network Bridge Properties] dialog box (if the box is not checked, proceed to step 6).
6. Click properties in [Internet Protocol Version 4 (TCP/IPv4)] in the [Network Bridge Properties] dialog box.
7. Click the [Alternate Configuration] tab in the [Internet Protocol Version 4 (TCP/IPv4) Properties] dialog box.
8. Check [User Configuration], and set the [IP address] and [subnetmask] as follows:
   IP address : 10. 10. 11. 101
   [subnetmask] : 255.255. 0. 0
   (If the above IP address is already in use in the LAN environment, change it as appropriate in Class A. Confirm to your system administrator on network settings before changing any settings.)
9. Click [OK]→ [Close].
10. Close the [Manage Network Connections] dialog box.
11. Close the [Network and Sharing Center] dialog box.

② **How to delete the Network Bridge.**

1. Select [Control Panel] from the [Start] menu, and double-click on [Network and Sharing Center].
2. Select [Manage network connections] in the [Network and Sharing Center] dialog box.
3. Right-click [Network Bridge] and click [Delete].
4. Click [Yes] in the [Confirm Connection Delete] dialog box.
5. Click [Continue] in [User Account Control].

Frequently Asked Questions (cont.)

No wireless connection can be made between my projector and my computer. (cont.)

<When Windows Firewall has been detected>

● **Windows XP**

Has Windows XP firewall been disabled?

The firewall in Windows XP must be disabled in order to connect to a wireless network.

■ **How to disable the firewall in Windows XP**

1. Click [Start] → [Control Panel] → [Network and Internet Connections] → [Network Connections].
2. Right-click [Wireless Network Connection] and click [Properties] in the pulldown menu.
3. Click the [Advanced] tab and set the [Internet Connection Firewall] checkbox to OFF.

● **Windows XP SP2**

Is Wireless Manager ME 5.5 registered in the [Control Panel] → [Security Center] → [Windows Firewall] → [Exception] tab with the Windows XP SP2.

Register Wireless Manager ME 5.5 in the Exceptions to Application List of the firewall.

■ **How to register**

1. Click [Start] → [Control Panel].
2. Click [Security Center] → [Windows Firewall] when <Control Panel> window opens.
3. Click the [Exceptions] tab and then [Add Program…] when the <Windows Firewall> window opens.
4. Click [Wireless Manager mobile edition 5.5 (WM.exe)] to allow connection with external devices under [Programs] when the <Add a Program> window opens.
   If [Wireless Manager mobile edition 5.5 (WM.exe)] does not appear on the list of programs, click [Browse...] and select [WM.exe].
5. [Wireless Manager mobile edition 5.5] is displayed in the [programs and services] field.
6. Double-click [Wireless Manager mobile edition 5.5], and open the [Edit a Program] window.
7. Click the [Change Scope] button at the lower left of the window.
8. When the [Change Scope] window opens, select the desired network as described below. Select [Any computer (including those on the Internet)].
9. Click [OK].
10. Click [OK] in the [Edit a Program] window.
11. Click [OK] in the [Windows Firewall] window.
    With this, the Wireless Manager ME 5.5 firewall will be deleted.

● **Windows Vista**

Is Wireless Manager ME 5.5 registered in the [Start] → [Control Panel] → [Windows Firewall] → [Allow a program through Windows Firewall] → [Exceptions] tab?

Register Wireless Manager ME 5.5 in the Exceptions to Application List of the firewall.

■ **How to Register**

1. Click [Start] → [Control Panel].
2. Double-click the [Windows Firewall] tab when the [Control Panel] window opens.
3. Click [Allow a program through Windows Firewall] when the [Windows Firewall] dialog box opens.
4. Click [Continue] in [User Account Control].
5. Click the [Exceptions] tab and then [Add program...] when the [Windows Firewall Settings] window opens.
6. Click [Wireless Manager mobile edition 5.5] when the [Add program...] window opens.
   If [Wireless Manager mobile edition 5.5] does not appear in [Programs], click [Browse...] and select [WM.exe].
7. [Wireless Manager mobile edition 5.5] is displayed in the [Program or port] field.
8. Double-click [Wireless Manager mobile edition 5.5], and open the [Edit a Program] window.
9. Click the [Change scope...] button at the lower left of the window.
10. When the [Change scope] window opens, select the desired network as described below. Select [Any computer (including those on the Internet)].
11. Click [OK]
12. Click [OK] in the [Edit a Program] window.
13. Click [OK] in the [Windows Firewall] window.
14. With this, the Wireless Manager ME 5.5 firewall will be deleted.

● **Windows 7**

Is this software registered in [Start] → [Control Panel] → [System and Security] → [Allow a program through Windows Firewall]?

■ **How to Register**

1. Click [Start] →[Control Panel].
2. Click [System and Security] when the [Control Panel] window opens.
3. Click [Allow a program through Windows Firewall] in the [System and Security] window.
4. Click the [Change settings] button to change to the allow registration mode.
5. Click the [Allow another program (R)…] button, select [Wireless Manager mobile edition 5.5], and click the [Add] button.
6. Confirm that this software has been added to the [Allowed programs and features (A):] list. Confirm that the Private and Public checkboxes are checked.
7. Click the [OK] button in the [Allow programs to communicate through Windows Firewall] window.
8. With this, the Wireless Manager ME 5.5 firewall will be deleted.

Frequently Asked Questions (cont.)

No wireless connection can be made between my projector and my computer. (cont.)

<When another firewall has been detected>

Are any firewall-containing applications installed?

If any applications which contain firewalls are installed, the installation may hang up at the [Projector search in progress] display (some firewalls function even when not started).
If this occurs, firewall settings must be changed in order to allow connection to the wireless network. See the User's Manuals for all applications containing firewalls to perform these settings.

<When the user does not have the administrator authority>

- If you have logged onto a computer as a [GUEST] or a restricted user who does not have administrator authority, you can not perform Easy Wireless Set Up ([S-MAP], Network No. [1] – [4]). If you must perform Easy Wireless Set Up without administrator authority, designate [USER1] - [USER3] as the network number.
  See pages 53 - 55 for instructions in how to set [USER1] - [USER3] as the network number.
- With the connection method in "When logging on without administrator authority," when the "Wireless Networks" tab is not shown, complete the following settings.
  1. Click [Start]→[Control Panel]→[Performance and Maintenance]→[Administrative Tools]→[Services].
     The <Services> window appears.
  2. Find [Wireless Zero Configuration] in the list.
  3. If the status is blank, right-click it and select [Properties].
  4. In [Service status], click [Start].
     If you cannot click the [Start] button for [Service status] (it is grayed out), check whether [Type of startup] is set to [Manual] or [Automatic]
  5. Click [OK].
     The status is now shown as [Started].
  6. Close the window.

<Network setting error>

Make sure that the projector's network setting is correct, if you log in as any of [USER1] through [USER3]. (See page 53)

<When network setting is done by using the connection utility>

Projector connection may be disengaged, if the wireless LAN adapter is automatically set by the connection utility.
If the connection with the projector is interrupted, it is recommended to use the product with the connection utility disabled.

<When Firewall/Connection Utility is detected>

If a Firewall is found active, the Firewall list is displayed
To deactivate a network block, click the [OK] button to deactivate or stop it.
The service that stopped when Wireless Manager ME 5.5 ended will return to the original state.

If the [The operation is always performed from next time.] box is checked, this message will not be displayed from the next time the application is started. You can display the message again by changing the settings in [Other2] in the options window.


Wireless Manager
Confirmation message
Firewall
Windows Firewall
Cisco VPN Service
A firewall was found.
To search for projectors and to connect, the firewall must be unblocked or stopped temporarily.
The state of the firewall is restored when quitting WirelessManager.
The following action(s) will be applied to the selected firewall:
· Unblock Windows firewall
· Stop Cisco VPN Service
The operation is always performed from next time.
O K
Cancel

screen ①

Frequently Asked Questions (cont.)

No wireless connection can be made between my projector and my computer. (cont.)

<When Firewall/Connection Utility is detected (continued)>

If the connection utility is active, the connection utility list is displayed.
To connecto to the projector, the connection utility must be stopped.
To stop the connection utility, click the [OK] button to stop the service.
The service that stopped when Wireless Manager ME 5.5 ended will return to the original state.

If the [The operation is always performed from next time.] box is checked, this message will not be displayed from the next time the application is started. You can display the message again by changing the settings in [Other2] in the options window.


Wireless Manager
Confirmation message
Wireless LAN Utility
Intel WLAN Utility
Linksys WPC54CFG
Wireless LAN adapter utility was found.
To search for projectors and connect, the firewall must be disabled temporarily.
Please select the Wireless LAN adapter utility to be stopped.
- Intel WLAN Utility(s24EventMonitor)
- Linksys WPC54CFG(NICSer_WPC54GS)
The state of the stopped Wireless LAN adapter utility is restored after quitting WirelessManager.
The operation is always performed from next time.
O K
Cancel
screen ②

<When the network is known to be blocked>

Before start Wireless Manager ME 5.5, deactivate the network block with a firewall.

The connection to the wireless LAN or wired LAN is lost.

- If the live mode is canceled or the connection is lost, start the reconnection procedure from the launcher. If it is still not possible to establish a connection to the LAN, power off the projector, wait for the cooling fan to stop operating (after the power monitor on the projector changes from orange to red), power the projector back on, and then start the connection procedure from the launcher once again. (See pages 15 or 28)

The connection has been lost in the multi live mode.

- If a computer with a certain version of the Intel Centrino mobile technology (wireless LAN) is connected to the unit, the multi live mode may be released. If this is the case, re-establish the connection from the launcher of Wireless Manager ME 5.5. (See page 32)

The connection cannot be established with IEEE802.11 g.

- In environments with wireless LAN adapters that support both IEEE802.11b and IEEE802.11g, the connection may be established via IEEE802.11b.
- In some operating environments, the connection may be established via IEEE802.11b, depending on the location, radio signal conditions, distance, or other factors.
- Some wireless LAN adapters only support AD HOC connections via IEEE802.11b.

The transfer rate is slow.

- The transfer rate may be slower in some operating environments (depending on such factors as the location, radio signal conditions or distance).
- Avoid placing metal objects or other conductors near the wireless LAN antenna of a computer, otherwise the transfer rate may be slower.
- When WEP is set the image data is converted, so transfer takes time.

Image display is slow or animation is not displayed smoothly.

- Is the computer CPU speed slow? (See page 12)
  Live mode depends largely upon the computer CPU performance.
- Adverse effects may be exerted if there is any wireless communication in the vicinity.
- When [Resolution] is set to [High Definition] in the <Option> window (See page 48), it may take longer time to display images.
- Did you start up Microsoft PowerPoint or Windows Media Player before starting up Wireless Manager ME 5.5?
  If so, start up the application only after you have started up Wireless Manager ME 5.5.
- The speed may drop significantly if the user does not have administrator authority.
- The speed may be slower when any other applications are running concurrently.
- Display may be slow when moving images are played in Windows Vista or Windows 7.

Contents of DVD or MPEG2 cannot be played on computer.

The following limitations apply when Wireless Manager ME 5.5 is running.

- DVD and MPEG2 playback is disabled.
- When using 3-D software, performance may be poor. Some items may not be rendered properly, and some operations may not work correctly.

To correct such problems, quit Wireless Manager ME 5.5 and use an RGB cable to connect the computer to the projector.

- Some moving image application programs can not replay moving images.

Frequently Asked Questions (cont.)

There is a time lag between operations at the computer and results in the projected image.

- Wireless Manager ME 5.5 reads the screen, compresses the data and transmits it to the projector. In the projector, the received data are extracted and then projected. Some delays occur in this system, due to the processing time and factors in the wireless environment. Different computers may also produce varying lag times.

I can't hear the computer sound from the projector in the live mode.

- Check whether the check mark has been entered for [Produce audio along with video at live mode] from [Live Mode Settings] under the [Transmission] tab selected from Wireless Manager ME 5.5's <Option> window. (See page 48)
- Did you start up a player (Windows Media Player, Real Player or Quick Time, etc.) before starting live mode? If so, start the application only after starting live mode.

● **Windows 7**

- While Wireless Manager ME 5.5 is running, click [Start] → [Control Panel] → [Hardware and Sound], and then select [Sound].
- Confirm whether "Panasonic Projector Audio Device" is set to "Default Device".
- If it is not set to "Default Device", select "Panasonic Projector Audio Device" and click the [Set Default] button.
- Click the [OK] button in the Sound window.

※The default device setting returns to its original state after this application ends.





Don't know to which projector the computer is connected in multiple source live mode or multiple source multi live mode.

- Connected projectors' names, IDs and their status are displayed in the pop up window when the cursor is on [ ] of the launcher.

Changing the display style.

- Press the remote control [MULTI-LIVE] button to change the display style.

The Wireless Manager ME 5.5 color display is strange and characters are difficult to read.

- Click [Start] → [Control panel] → [Appearance and Themes] → [Display]. Then, open the [Settings] tab of the <Display Properties> window and set [Color quality] to [Medium (16 bit)] or higher.

Screen saver is not displayed properly in live mode.

- Some screen savers may not be displayed properly in the live mode. Check the [Disable screen saver] box in [Live Mode Settings] in the <Option> window of Wireless Manager ME 5.5. (See page 48)

Making a wireless LAN connection while using the internet

- If you have a wireless LAN environment which allows an internet connection, you can use both the Internet and wireless LAN connection at the same time by integrating a projector in this environment. (See page 24)
- If you have a wired internet connection (Ethernet), this projector allows wireless use with simultaneous wired connection to the internet.

The web control window does not appear.

<When Easy Wireless Set Up connection is used>

- When any WebBrowser except Internet Explorer is used, the proxy settings of the WebBrowser must be manually released.

<When [USER] connection is used>

- Manually release the proxy settings of the WebBrowser used.

Frequently Asked Questions (cont.)

When Windows Media Player 11 is used with Windows Vista or Windows 7, there are dropouts in the audio when in the live mode.
• When using Windows Media Player 11, close as many other running programs as possible. If there still are dropouts in the audio, try using another player application.
When using Wireless Manager ME 5.5 with Windows Vista or Windows 7, the launcher is projected.
• This limitation applies when installing and using the software in Windows Vista or Windows 7. The launcher can be set not to be displayed by minimizing it to the task tray.
The “Aero” setting is cancelled.
• When Wireless Manager ME 5.5 is running, the “Aero” setting is cancelled.

Trademarks

- Microsoft and its logo as well as Windows, Windows® XP, Windows Vista®, Windows® 7, Windows Media, Microsoft Office and PowerPoint are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Intel, Pentium and Centrino are registered trademarks or trademarks of Intel Corporation or its affiliates in the United States and other countries.
- Other company names, product names or other names noted in this manual are trademarks or registered trademarks of the respective companies. Note that ® and TM marks are not indicated in the text of this manual.

Notes:
- Unauthorized use or reproduction of part or all of this product software and manuals is strictly prohibited.
- Panasonic cannot be held liable for any effects resulting from the use of this product software and manuals.
- Panasonic reserves the right to revise this product software specifications and manual contents without notice.

Panasonic Corporation

Web Site : http://panasonic.net/avc/projector/
© Panasonic Corporation 2009

Panasonic Broadcast & Television Systems Company
Unit of Panasonic Corporation of North America
One Panasonic Way, Secaucus, NJ 07094
TEL: (201) 348 - 7000

Technical Support:
TEL: (888) 411 - 1996
FAX: (201) 348 - 7523
E-Mail: projectorsupport@us.panasonic.com

Panasonic Canada Inc.
5770 Ambler Drive, Mississauga, Ontario L4W 2T3
TEL: (905) 624 - 5010

S0809-3D